

ROMEO TPM Function List (Note:For reference only)

NOTES:

- This function is supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported.
- ▲ This function is the new feature in this version.

Model	Year/Engine	TPM
159	1.8 16V	●
159	1.8 JTS TB 16V	●
159	1.9 JTS 16V	●
159	1.9 MJET 16V	●
159	1.9 MJET 8V	●
159	2.0 JTD 16V	●
159	2.2 JTS 16V	●
159	2.4 MJET 20V	●
159	3.2 V6 24V	●
4C	2013	●
BRERA	1.8 JTS TB 16V	●
BRERA	2.0 JTD 16V	●
BRERA	2.2 JTS 16V	●
BRERA	2.4 MJET 20V	●
BRERA	3.2 V6 24V	●
MITO	1.3 MJET 16V	●
MITO	1.4 16V	●
MITO	1.4 8V	●
MITO	1.4 TURBO 16V	●
MITO	1.6 MJET 16V	●
MITO	2008	●

TPM Function List

- Activate TPM High Gain Mode
- Alarm Deletion
- Alarm State Check
- Antenna Replacement
- Clear TPM Sensor Rolls Test Results
- Clear TPM Warnings
- Control Unit Activation
- Control Unit Deactivation
- Control Unit Replacement
- ECU SERIAL NUMBER Management
- Looks For Faunty Wheel Transmitter
- Manual System Configuration
- Program Tire Sensor ID
- Reset TPMS Calibration
- TPM Sensor Position Parameter Update
- TPM Sensor Rolls Test
- TPMS Calibration
- TPMS Reset Calibration
- Tyre Pressure Check
- Update Front And Rear Axle Nominal Tire Pressure Values
- Wheel Identification Check
- Wheel Transmitters Learning
- Write Front And Rear Axle Nominal Tire Pressure
- Write Front And Rear Nominal Tire Pressure Values