

CITROEN BLD Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | Model Type | BLD |
|----------------|--------------------------------------|-----|
| BERLINGO | BERLINGO (2) (2002 - 2008) | ● |
| BERLINGO | BERLINGO (2) (M69) | ● |
| BERLINGO | BERLINGO (B9) | ● |
| BERLINGO | BERLINGO Electric (B9E) | ● |
| C-ELYSEE | C-ELYSEE | ● |
| C-QUATRE | C-QUATRE (4) | ● |
| C-QUATRE | C-QUATRE (5) | ● |
| C-TRIOMPHE | | ● |
| C3 | C3 (A51) | ● |
| C3 | C3 (Ai51) | ● |
| C3 | C3 (AIRCROSS) (A88) | ● |
| C3 | C3 (AIRCROSS) (Ai58) | ● |
| C3 | C3 (B618) | ● |
| C3 | C3 (PICASSO) (A58) | ● |
| C3 | C3 (PICASSO) (Ai58) | ● |
| C3 | C3 (XR) | ● |
| C4 | C4 (2004 - 2010) | ● |
| C4 | C4 (B7) (2010 -) | ● |
| C4 | C4 (BZ3) (CHINA) | ● |
| C4 | C4 (L) (B7) | ● |
| C4 | C4 (PICASSO) (2006 - 2013) | ● |
| C4 | C4 (PICASSO) (B78) (2013 -) | ● |
| C4 | C4 (SEDAN) (2006 -) | ● |
| C5 | C5 (3rd Generation) | ● |
| C5 | C5 (AIRCROSS) | ● |
| C5 | C5 (X7) (2007 -) | ● |
| C6 | C6 | ● |
| C6 | C6 (CHINA) | ● |
| C8 | C8 (CAN) (2005 -) | ● |
| JUMPER/RELAY | JUMPER/RELAY (3) (2006 - 2011) | ● |
| JUMPER/RELAY | JUMPER/RELAY (3) (MiniBus) (2006 -) | ● |
| JUMPY/DISPATCH | JUMPY/DISPATCH (3) (2007 - 2016) | ● |
| JUMPY/DISPATCH | JUMPY/DISPATCH (K0) (2016 -) | ● |
| SPACETOURER | | ● |

CITRONE BLD Function List (Note:For reference only)

Bleeding

Bleeding Of The Hydraulic Block

Bleeding Of The Hydraulic Block ABS MK100

Bleeding Of The Hydraulic Block ASR8.0

Bleeding Of The Hydraulic Block ESP MK100

Bleeding Of The Hydraulic Circuit