CITROEN DPF Function List (Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Model | Model Type | DPF |
|----------------|---|-----|
| BERLINGO | BERLINGO (2) (M69) | • |
| BERLINGO | BERLINGO (B9) | • |
| C-CROSSER | | • |
| C-ELYSEE | C-ELYSEE | • |
| C2 | C2 (CAN) (2006 -) | • |
| C3 | C3 (A51) | • |
| C3 | C3 (AIRCROSS) (A88) | • |
| C3 | C3 (B618) | • |
| C3 | C3 (PICASSO) (A58) | • |
| C4 | C4 (2004 - 2010) | • |
| C4 | C4 (B7) (2010 -) | • |
| C4 | C4 (CACTUS) | • |
| C4 | C4 (L) (B7) | • |
| C4 | C4 (PICASSO) (2006 - 2013) | • |
| C4 | C4 (PICASSO) (B78) (2013 -) | • |
| C4 | C4 (SEDAN) (2006 -) | • |
| C5 | C5 (2001 - 2004) | • |
| C5 | C5 (R) (2004 - 2007) | • |
| C5 | C5 (X7) (2007 -) | • |
| C6 | C6 | • |
| C8 | C8 (CAN) (2005 -) | • |
| C8 | C8 (VAN) (2002 - 2005) | • |
| JUMPER/RELAY | JUMPER/RELAY (3) (2006 - 2011) | • |
| JUMPER/RELAY | JUMPER/RELAY (3) (Euro 5 / 6) (2011 -) | • |
| JUMPER/RELAY | JUMPER/RELAY (3) (MiniBus) (2006 -) | • |
| JUMPY/DISPATCH | JUMPY/DISPATCH (3) (2007 - 2016) | • |
| JUMPY/DISPATCH | JUMPY/DISPATCH (K0) (2016 -) | • |
| SPACETOURER | | • |
| XSARA | XSARA (2) (2000 - 2006) | • |
| XSARA | XSARA (PICASSO) (2002 - 2006) | • |
| XSARA | XSARA (PICASSO) (CHINA) | • |

CITRONE DPF Function List (Note:For reference only)

| Filling Of The Diesel Add | itive Adding Reservoir | |
|---------------------------|------------------------|--|
|---------------------------|------------------------|--|

Forced Regeneration Of The Particle Emission Filter

Forced Regeneration Of The Particle Filter, Vehicle Stationary

Forced Regeneration Of The Particulate Filter While Driving

Forced Regeneration Vehicle Moving

Forced Regeneration Vehicle Stationary

Pariticle Filter Regeneration

Particulate Filter Replacement

Replacement Of The Diesel Additive Reservoir, Of The Pump Or Of The Pipes

Replacement Of The Differential Pressure Sensor

Replacement Of The Particle Emission Filter

Replacement Of The Particle Emission Filter Differential Pressure Sensor