AUDI Diagnostic Fund	ction List(Note:For reference only)						
NOTES:							
 This function is supported. 							
= =	epends on the actual condition of the vehicle.						
O This function is not supported.							
▲ This function is the new feature in this	s version.						
Vehicle	Year						
A1	2011 - 2019						
A2	2001 - 2006						
A3	1997 - 2019						
A4	1998 - 2019						
A5	2008 - 2019						
A6	1998 - 2019						
A7	2011 - 2019						
A8	1999 - 2019						
Cabriolet	2003 - 2009						
Q3	2012 - 2019						
Q5	2009 - 2019						
Q7	2007 - 2019						
R8	2007 - 2019						
ТТ	1999 - 2019						
Systemlist	EcuInfo Read Erase Live Actuation Basic Adaptation						
01 Engine Control Module 1	. Codes Codes Data Test Settings						
01 Engine Control Module 1 02 Transmission Control Module							
03 Brakes 1							
04 Steering Angle Sender							
05 Kessy							
06 Seat Adjustment Passenger Side							
07 Display Control Unit							
08 Air Conditioning							
09 Central Electrics							
OB Auxiliary Air Heater							
OC Rear Axle Steering 2							
OD Sliding Door Left							
OE Media Player Position 1							
OF Radio Tuner - Digital	$\begin{array}{c c c c c c c c c c c c c c c c c c c $						
10 Parking Assistance 2							
11 Engine Control Module 2 12 Clutch Control Unit							
13 Adaptive Cruise Control							
· · · · · · · · · · · · · · · · · · ·							
14 Wheel Dampening Electronics							
15 Airbag							
16 Steering Column Electronics 17 Dash Board							
	$\begin{array}{c c c c c c c c c c c c c c c c c c c $						
18 Auxiliary Parking Heater							
19 Gateway							
1A Fuel Cell Engine	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$						
1B Active Steering							
1C Vehicle Position Detection 1D Driver Identification							
1E Media Player Position 2							
20 High Beam Assistance							
21 Battery Energy Control Module 2							
22 All Wheel Control							

23 Brake Boost						0	0
25 Immobilizer						0	0
26 Electronic Roof Control		•	•	•	•	0	0
27 Display Control Unit Rear		•	•	•	•	0	0
28 Climate Control Unit Rear						0	0
29 Light Control Left		•	•	•	•	0	0
24 Control Unit Wireless Charging		•	•	•	•	0	0
						0	0
2B Steering Column Locking	-						0
2D Voice Amplifier	•	•	•	•	•	0	
2E Media Player Position 3	•	•	•	•	•	0	0
30 Special Function 2	•	•			•	0	0
31 Engine Electronics Group	•	•	•	•	•	0	0
32 Lock Electronics	•	•	•	•	•	0	0
33 All OBD Systems	•	•	•	•	•	0	0
34 Ride Control System	•	•	•	•	•	0	0
35 Central Locking Control Module	•	•	•	•		0	0
36 Seat Adjustment Driver Side	•	•		•		0	0
37 Navigation	•	•	•	•		0	0
38 Roof Electronic Control Module	•	•	•	•		0	0
39 Light Control Right	•	●		•		0	0
3A Special Vehicle Assistant	•	●		•	•	0	0
3B Sensor Electronics	●	●		•	•	0	0
3C Lane Change Assistant	●	●		•	•	0	0
3D Special Function	•			•	•	0	0
3E Media Player Position 4	●	\bullet		\bullet		0	0
3F Dynamic Assembly Mounting	●	\bullet		\bullet		0	0
40 Air Conditioning Compressor	\bullet			•	•	0	0
41 Diesel Pump Electronics				•		0	0
42 Door Electronics Driver Side	\bullet			•	•	0	0
43 Bremskraftunterstutzung	•	•		•	•	0	0
44 Steering Assistance	•			•	•		•
45 Interior Monitoring	•			•	•	0	0
46 Central Module Comfort System	•			•	•		•
47 Sound System	•			•	•	0	0
48 Seat Adjustment Rear Driver Side	•			•	•	0	0
4A Rear Light	•					0	0
4B Multifunction Module	•	•				0	0
4C Tire Pressure Monitoring 2	•	•		•		0	0
4D Data Transfer Car2X XXX	•	•	•	•	•	0	0
4E Control Head Rear Right	•	•	•	•	•	0	0
4F Central Electrics 2	•	•			•	0	0
50 Seat Adjustment 3rd Row	•	•	•	•	•	0	0
51 Drive Motor Control Module						0	0
52 Door Electronics Passenger Side			•	•	•	0	0
53 Parking Brake					•		
54 Rear Spoiler						0	0
55 Headlight Regulation		•	•		•	0	0
56 Radio		•	•	•	•	0	0
57 TV Tuner	-	•				0	0
58 Fuel Supply	•	•	•	•	•	0	0
5A Longitudinal Control	•	•	•	•	•	0	0
5B Seat Adjustment Rear Passenger Side	•	•	•			0	0
5C Lane Departure Warning System	•	•	•	•	•	0	0
5D Operation	●	●				0	0

5E Control Head Rear Left \bullet \bullet	• • 0	
5F Information Control Unit 1		
60 Tachograph $\bullet \bullet$		
62 Door Electronics Rear Left • •		
63 Entry Assistance Driver Side		
	$\bullet \bullet \circ$	
65 Tire Pressure Monitoring 1		
66 Seat Adjustment Rear		
67 Voice Control		
68 Wiper Control Unit		
6B Aerodynamics Control Unit • • •		
6C Camera System Rear View		
6D Deck Lid Control Unit		
6E Display Control Roof		
71 Battery Charger		
72 Door Electronics Rear Right • •		
73 Entry Assistance Passenger Side••74 Chassis Control••		
75 Telematics Communication Unit		
		-
77 Telephone • • •		
78 Sliding Door Right		
7A Door Automatic Rear Passenger Side		
7D Auxiliary Heater		
7E Dash Board Display Unit		
7F Information Control Unit 2		
80 Battery Regulation Auxiliary Accumulator 1		
81 Gear Shift Control Module		
84 Night Vision • • •		
85 On-Board Camera		
87 Lane Assist LT3		
89 Multi Contour Seat Passenger Side		
8A Multi Contour Seat Rear Driver Side		
8B Adaptive Cruise Control 2		
8C Battery Energy Control Module		
8D Multi Contour Seat Rear Passenger Side • •		
8E Image Processing Electronics		
8F Pretensioner Front Left		
90 Pretensioner Front Right		
91 Engine Control Module (ECM) • •	• • 0	
92 Transmission Electronics		
93 Immobilizer • • •	• • 0	
94 Airbag (SRS) • •	• • C	
95 Electronic Stability Program • • •	• • C	
96 Instrument Cluster • • •	• • C	
97 Tachograph • •	• • C	
98 Tire Pressure Monitoring • • •	• • C	
99 Electrical Ignition/starter Switch • • •	• • C	

9A Remote Control			0	0
9A Remote Control 9B Driver's Door Electronics			0	0
9C A/C Electronics			0	0
9D Auxiliary Heater (Fuel)			0	0
			0	0
9E Auxiliary Heater (Electric)			0	0
9F Parking Heater, Water			0	0
A0 Audio 5 Radio,			+ +	-
A1 Navigation			0	0
A2 CD Changer			0	0
A3 Telephone			0	0
A5 Front Sensors Driver Assistance System			0	0
A6 Microphone Control Unit			0	0
A7 Infotainment Interface			_	-
A8 External Communication InterfaceA9 Actuator For Structure-Borne Sound			0	0
			0	0
AA Wheel Brake Rear Right			0	0
AB Wheel Brake Rear Left			0	0
AC Reductant Control Module			0	0
AD Sensors Brake Systems	••	• •	0	0
AE Telemetry Diagnostic Control Unit	••		0	0
B0 Roof Display/control Head (Roof Control Head)	••	• •	0	0
B1 Upper Operating Field	••	• •	0	0
B2 Parking Aid	••		0	0
B3 Trailer Function	••	• •	0	0
B4 Vehicle Electrical System Control Module	••		0	0
B5 Programmable Special Module	••		0	0
B6 Steering Column Jacket Switch Module	••	• •	0	0
B7 Access Startsystem Interface	••	• •	0	0
B8 Electronic Roof Control 2	••		0	0
B9 Auxiliary Display Control Unit	••		0	0
BA Assembly Mounting	••		0	0
BB Door Electronics Rear Driver Side	••		0	0
BC Door Electronics Rear Passenger Side	• •	• •	0	0
BD High Voltage Battery Charge Management	••		0	0
BE Sliding Door Rear Left	••	• •	0	0
BF Sliding Door Rear Right	••	• •	0	0
CO Actuator For Exterior Noise	• •	• •	0	0
C1 Battery Regulation	••	• •	0	0
C2 Transmission Control Module 2	• •	• •	0	0
C3 Drive Motor Control Module 3	••	• •	0	0
C4 DC/DC Converter Control Module	• •	• •	0	0
C5 Thermal Management •	••	• •	0	0
C6 Battery Charger Control Module	• •	• •	0	0
C7 Pedestrian Protection	• •	• •	0	0
C8 Auxiliary Display Control Unit 2	• •		0	0
C9 Rear Mirror		• •	0	0
CA Control Module For Sunroof	• •	• •	0	0
CB Rear Axle Steering	• •	• •	0	0
CC Starter / Generator Control Module		• •	0	0
CD Laser Scanner •	• •	• •	0	0
CE Drive Motor Control Module 2	• •	• •	0	0
CF Control Unit Lane Change Assistant 2		• •	0	0
DO Front Axle Lift System •	• •	• •	0	0
D1 Center Display •			0	0

D2 Sliding Door Left			•	0	0
D3 Sliding Door Right			•	0	0
D4 Roll Control System 1		•		0	0
D5 Roll Control System 2		•	•	0	0
D6 Light Control Left 2		•	•	0	0
D7 Light Control Right 2		•	•	0	0
D8 Projection Module in Left Matrix Headlamp		•		0	0
D9 Projection Module in Right Matrix Headlamp		•	•	0	0
DB Front Corner Radar 1	•	•		0	0
DC Front Corner Radar 2		•	•	0	0
DD Control Module 2 For Sunroof	\bullet	•		0	0
DE Charger 1 Mobile Devices		•		0	0
DF Charger 2 Mobile Devices		•	•	0	0
EO Auxiliary Display Control Unit 1		•		0	0
EF Reference Control Unit			•	0	0