

DACIA BMS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model               | BMS |
|---------------------|-----|
| DUSTER              | ●   |
| DUSTER PH3          | ●   |
| LOGAN               | ●   |
| LOGAN II/SANDERO II | ●   |
| SANDERO             | ●   |

BMS Function List

|                                     |
|-------------------------------------|
| Autonomy Battery                    |
| Battery Corrosion Counter           |
| Calculate Battery Wear Counters     |
| Corrosion Battery Counter Memorised |
| Corrosion Battery Counter Estimated |
| Battery Cycle Counter Memorised     |
| Battery Cycle Counter Estimated     |
| Battery Cycle Counter               |
| Timed + Batt                        |
| 100 Ah Traction Battery             |
| Change Battery Compartment          |
| Battery Filling Reinitialisation    |
| Internal Battery                    |
| Traction Battery Relay              |