

FIAT LAP Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Year/Engine	LAP
500	0.9 TURBO TWIN AIR	●
500	1.2 8V	●
500	1.3 JTD	●
500	1.4 16V	●
500	1.4 TURBO 16V	●
500	2012	●
500	2013	●
500	2014	●
500	2015	●
BRAVO (198)	1.4 16V	●
BRAVO (198)	1.4 TURBO 16V	●
BRAVO (198)	1.6 MJET 16V	●
BRAVO (198)	1.9 MJET 16V	●
BRAVO (198)	1.9 MJET 8V	●
BRAVO (198)	2.0 MJET 16V	●
BRAVO VAN	1.6 MJET 16V	●
CROMA (194)	1.8 16V	●
CROMA (194)	1.9 MJET 16V	●
CROMA (194)	1.9 MJET 8V	●
CROMA (194)	2.2 16V	●
CROMA (194)	2.4 MJET 20V	●
DOBLO' (152)	1.3 MJET 16V	●
DOBLO' (152)	1.4 16V	●
DOBLO' (152)	1.6 MJET 16V	●
DOBLO' (152)	2.0 MJET 16V	●
DOBLO' (152)	NATURAL POWER	●
DOBLO' (223)	1.2 8V	●
DOBLO' (223)	1.3 JTD	●
DOBLO' (223)	1.4 8V	●
DOBLO' (223)	1.6 16V	●
DOBLO' (223)	1.8 8V	●
DOBLO' (223)	1.9 DS	●
DOBLO' (223)	1.9 JTD	●
DOBLO' (223)	BIPOWER-GPOWER	●
DOBLO' (263)	1.3MJET 16V	●
DOBLO' (263)	1.4 16V	●
DOBLO' (263)	1.6 MJET 16V	●
DOBLO' (263)	2.0 MJET 16V	●
DOBLO' (263)	NATURAL POWER	●
DOBLO' CARGO (223)	1.3 JTD	●
DOBLO' CARGO (223)	1.4 8V	●
DOBLO' CARGO (223)	1.9 JTD	●
DOBLO' CARGO (223)	BIPOWER-GPOWER	●
DUCATO (250)	2.2 JTD	●
DUCATO (250)	2.3 JTD	●
DUCATO (250)	3.0 16V CNG	●
DUCATO (250)	3.0 JTD	●
DUCATO (250)	MINIBUS 16+1 SEATS	●
DUCATO (250)	MINIBUS 3.0 16V CNG	●
DUCATO FL (250)	2.0 JTD	●
DUCATO FL (250)	2.3 JTD	●
DUCATO FL (250)	3.0 JTD	●
FIORINO (225)	1.3 JTD	●
FIORINO (225)	1.4 8V	●

GRANDE PUNTO VAN	1.3 MJET 16V	●
GRANDE PUNTO VAN	1.4 8V	●
Grande PUNTO	1.2 8V	●
Grande PUNTO	1.3 MJET 16V	●
Grande PUNTO	1.4 16V	●
Grande PUNTO	1.4 8V	●
Grande PUNTO	1.4 TURBO 16V	●
Grande PUNTO	1.6 MJET 16V	●
Grande PUNTO	1.9 MJET 8V	●
IDEA	1.2 16V	●
IDEA	1.3 JTD	●
IDEA	1.4 16V	●
IDEA	1.4 8V	●
IDEA	1.6 16V	●
IDEA	1.6 MJET 16V	●
IDEA	1.8 8V	●
IDEA	1.9 JTD	●
IDEA VAN	1.3 JTD	●
IDEA VAN	1.4 16V	●
LINEA	1.3 JTD	●
LINEA	1.4 16V	●
LINEA	1.4 8V	●
LINEA	1.4 TURBO 16V	●
LINEA	1.6 16V	●
LINEA	1.6 JTD	●
LINEA	1.8 16V	●
LINEA	1.9 16V	●
PALIO RST 2	1.0 8V	●
PALIO RST 2	1.1 8V	●
PALIO RST 2	1.2 16V	●
PALIO RST 2	1.3 JTD	●
PALIO RST 2	1.4 8V	●
PALIO RST 2	1.6 16V	●
PALIO RST 2	1.7 TD	●
PALIO RST 2	1.8 8V	●
PALIO RST 2	1.9 D	●
PANDA (169)	'03 1.1 8V	●
PANDA (169)	'03 1.2 8V	●
PANDA (169)	'03 1.3 JTD	●
PANDA (169)	'06 1.4 16V	●
PANDA (169)	'07 BIPOWER	●
PANDA (169)	'10 NATURAL BIPOWER	●
PANDA VAN	'03 1.1 8V	●
PANDA VAN	'03 1.2 8V	●
PANDA VAN	'03 1.3 JTD	●
PANDA VAN	'07 BIPOWER	●
PANDA VAN	'10 NATURAL BIPOWER	●
PERLA	1.7 8V	●
PUNTO (188)	'03 1.2 16V	●
PUNTO (188)	'03 1.2 8V	●
PUNTO (188)	'03 1.3 JTD	●
PUNTO (188)	'03 1.4 16V	●
PUNTO (188)	'03 1.8 16V	●
PUNTO (188)	'03 1.9 JTD	●
PUNTO (188)	'03 BIPOWER	●
PUNTO (188)	'99 1.2 16V	●
PUNTO (188)	'99 1.2 8V	●
PUNTO (188)	'99 1.8 16V	●
PUNTO (188)	'99 1.9 D	●
PUNTO (188)	'99 1.9 JTD	●
PUNTO EVO	2009	●
PUNTO EVO (199)	1.2 8V	●

PUNTO EVO (199)	1.3 MJET 16V	●
PUNTO EVO (199)	1.4 16V M. AIR	●
PUNTO EVO (199)	1.4 8V	●
PUNTO EVO (199)	1.4 TURBO 16V M. AIR	●
PUNTO EVO (199)	1.6 MJET 16V	●
PUNTO EVO VAN (199)	1.3 MJET 16V	●
PUNTO EVO VAN (199)	1.4 8V	●
PUNTO INTERN. (118)	1.2 8V	●
PUNTO INTERN. (118)	1.3 JTD	●
PUNTO INTERN. (118)	1.4 16V	●
PUNTO INTERN. (118)	1.4 8V	●
PUNTO INTERN. (118)	1.4 TURBO 16V	●
PUNTO INTERN. (118)	1.6 16V	●
PUNTO INTERN. (118)	1.8 8V	●
PUNTO VAN	'03 1.2 8V	●
PUNTO VAN	'03 1.3 JTD	●
PUNTO VAN	'03 BIPOWER	●
QUBO	1.3 JTD	●
QUBO	1.4 8V	●
STILO	1.2 16V	●
STILO	1.4 16V	●
STILO	1.6 16V	●
STILO	1.8 16V	●
STILO	1.8 8V	●
STILO	1.9 JTD	●
STILO	1.9 JTD 16V	●
STILO	2.4 20V	●
STILO	SELESPEED	●
STILO VAN	1.9 JTD 16V	●
STRADA	1.3 JTD	●
STRADA	1.4 8V	●
STRADA	1.6 16V	●
ULYSSE '02	2.0 16V	●
ULYSSE '02	2.0 JTD 16V	●
ULYSSE '02	2.2 JTD 16V	●
ULYSSE '02	3.0 V6 24V	●
ULYSSE (179)	2.0 JTD 16V	●
ULYSSE (179)	2.2 JTD 16V	●
ULYSSE VAN	2.0 JTD 16V	●

FIAT(CHINA) LAP Function List (Note:For reference only)

PALIO RST 2(CHINA)	1.0 8V	●
PALIO RST 2(CHINA)	1.1 8V	●
PALIO RST 2(CHINA)	1.2 16V	●
PALIO RST 2(CHINA)	1.3 JTD	●
PALIO RST 2(CHINA)	1.4 8V	●
PALIO RST 2(CHINA)	1.6 16V	●
PALIO RST 2(CHINA)	1.7 TD	●
PALIO RST 2(CHINA)	1.8 8V	●
PALIO RST 2(CHINA)	1.9 D	●
PERLA(CHINA)	1.7 8V	●

LAP Function List

AFLS Calibration
Enable Front Fog Lamp Output
Enable/Disable Front Fog Lamp
Flash Hazard Lamps On Lock
Head Lamp Levelling
Headlamp Actuators
Headlamp Delay Time
Headlamp Position Correct
Headlight Actuators - High

Headlight Actuators - Intermediate
Headlight Actuators - Low
Illuminated Entry Time
System Calibration