

LandRover OTHER Fuction List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

VehicleType	ModelYear	Engine	OTHER
Defender	1997-2006	NONE	●
Defender	2007-2010	Diesel I4 2.4L	●
Defender	2011	Diesel I4 2.4L	●
Discovery	2005-2009 (Dis 3)	Normally aspirated V6	●
Discovery	2005-2009 (Dis 3)	Normally aspirated V8	●
Discovery	2005-2009 (Dis 3)	Diesel V6	●
Discovery	2010-2011	Normally aspirated V6 4.0L	●
Discovery	2010-2011	Normally aspirated V8 5.0L	●
Discovery	2010-2011	Diesel V6 2.7L	●
Discovery	2010-2011	Diesel V6 3.0L	●
Discovery	2012-2013	Diesel V6 2.7L	●
Discovery	2012-2013	Diesel V6 3.0L	●
Discovery	2012-2013	Normally aspirated V8 5.0L	●
Discovery	2014-2015	Diesel V6	●
Discovery	2014-2015	Supercharged V6	●
Discovery	2017-	V8 5.0L Petrol	●
Discovery	2017-	V6 3.0L Diesel	●
Discovery	2017-	AJ200D 2.0L Diesel	●
Discovery	2017-	V6 3.0L Petrol	●
Discovery	2017-	PT204 2.0L Petrol	●
Discovery Sport	2015-2016	Diesel I4 2.2L	●
Discovery Sport	2015-2016	GTDI 2.0L Petrol	●
Discovery Sport	2017	GTDI 2.0L Petrol	●
Discovery Sport	2017	Diesel I4 2.0L	●
Discovery Sport	2018	DW12 2.2L Diesel	●
Discovery Sport	2018	GTDI 2.0L Petrol	●
Discovery Sport	2018	AJ200D 2.0L Diesel	●
Discovery Sport	2018	AJ200P 2.0L Petrol	●
Freelander	2007-2010	Diesel I4	●
Freelander	2007-2010	Petrol I6	●
Freelander	2011-2012	GTDI 2.0L	●
Freelander	2011-2012	Diesel I4	●
Freelander	2011-2012	Petrol I6	●
Freelander	2013-2014	GTDI 2.0L	●
Freelander	2013-2014	Diesel I4	●
Range Rover	2006	Normally aspirated V8	●
Range Rover	2006	Supercharged V8	●
Range Rover	2006	Diesel straight six	●
Range Rover	2007-2009	Diesel V8	●
Range Rover	2007-2009	Normally aspirated V8	●
Range Rover	2007-2009	Supercharged V8	●
Range Rover	2010-2012	Diesel V8	●
Range Rover	2010-2012	Normally aspirated V8	●
Range Rover	2010-2012	Supercharged V8	●

Range Rover	2013	Diesel V8 4.4L	●
Range Rover	2013	Diesel V6 3.0L	●
Range Rover	2013	Supercharged V8	●
Range Rover	2013	Normally aspirated V8	●
Range Rover	2014-2015	Hybrid 3.0L	●
Range Rover	2014-2015	Supercharged V6	●
Range Rover	2014-2015	Normally aspirated V8	●
Range Rover	2014-2015	Supercharged V8	●
Range Rover	2014-2015	Diesel V6 3.0L	●
Range Rover	2014-2015	Diesel V8 4.4L	●
Range Rover	2014-2015	GTDI 2.0L	●
Range Rover	2016	Diesel V8 4.4L	●
Range Rover	2016	Hybrid 3.0L	●
Range Rover	2016	GTDI 2.0L	●
Range Rover	2016	Diesel V6 3.0L	●
Range Rover	2016	Normally aspirated V8 5.0L	●
Range Rover	2016	Supercharged V8 5.0L	●
Range Rover	2016	Supercharged V6 3.0L	●
Range Rover	2017-	V8 5.0L Petrol	●
Range Rover	2017-	V8 4.4L Diesel	●
Range Rover	2017-	V6 3.0L Diesel	●
Range Rover	2017-	V6 3.0L Diesel Hybrid	●
Range Rover	2017-	V6 3.0L Petrol	●
Range Rover	2017-	AJ200P 2.0L Petrol	●
Range Rover	2017-	PT204 2.0L Petrol Plug-in Hybrid	●
Range Rover Sport	2005(2006US)-2009	Normally aspirated V8	●
Range Rover Sport	2005(2006US)-2009	Supercharged V8	●
Range Rover Sport	2005(2006US)-2009	Diesel V6	●
Range Rover Sport	2005(2006US)-2009	Diesel V8	●
Range Rover Sport	2010-2011	Normally aspirated V8 5.0L	●
Range Rover Sport	2010-2011	Supercharged V8 5.0L	●
Range Rover Sport	2010-2011	Diesel V6 3.0L	●
Range Rover Sport	2010-2011	Diesel V8 3.6L	●
Range Rover Sport	2012-2013	Diesel V6 3.0L	●
Range Rover Sport	2012-2013	Normally aspirated V8 5.0L	●
Range Rover Sport	2012-2013	Supercharged V8 5.0L	●
Range Rover Sport	2014-2015	Hybrid 3.0L	●
Range Rover Sport	2014-2015	Supercharged V6	●
Range Rover Sport	2014-2015	Normally aspirated V8	●
Range Rover Sport	2014-2015	Supercharged V8	●
Range Rover Sport	2014-2015	Diesel V6 3.0L	●
Range Rover Sport	2014-2015	Diesel V8 4.4L	●
Range Rover Sport	2014-2015	GTDI 2.0L	●
Range Rover Sport	2016	Diesel V8 4.4L	●
Range Rover Sport	2016	Hybrid 3.0L	●
Range Rover Sport	2016	GTDI 2.0L	●
Range Rover Sport	2016	Diesel V6 3.0L	●
Range Rover Sport	2016	Supercharged V8 5.0L	●
Range Rover Sport	2016	Supercharged V6 3.0L	●
Range Rover Sport	2017-	V8 5.0L Petrol	●
Range Rover Sport	2017-	V8 4.4L Diesel	●
Range Rover Sport	2017-	V6 3.0L Diesel	●

Range Rover Sport	2017-	V6 3.0L Diesel Hybrid	●
Range Rover Sport	2017-	AJ200D 2.0L Diesel	●
Range Rover Sport	2017-	V6 3.0L Petrol	●
Range Rover Sport	2017-	PT204 2.0L Petrol	●
Range Rover Sport	2017-	PT204 2.0L Petrol Plug-in Hybrid	●
Range Rover Sport	2017-	AJ20 P6 3.0L Petrol Mid Hybrid MHEV	●
Range Rover Evoque	2012-2013	GTDI 2.0L	●
Range Rover Evoque	2012-2013	Diesel I4 2.2L	●
Range Rover Evoque	2014-2015	Diesel I4 2.4L	●
Range Rover Evoque	2014-2015	GTDI 2.0L	●
Range Rover Evoque	2016	Diesel I4 2.2L	●
Range Rover Evoque	2016	GTDI 2.0L	●
Range Rover Evoque	2016	Diesel I4 2.0L	●
Range Rover Evoque	2017	GTDI 2.0L	●
Range Rover Evoque	2017	Diesel I4 2.0L	●
Range Rover Evoque	2018-	DW12 2.2L Diesel	●
Range Rover Evoque	2018-	GTDI 2.2L Petrol	●
Range Rover Evoque	2018-	AJ200D 2.0L Diesel	●
Range Rover Evoque	2018-	AJ200P 2.0L Petrol	●
Range Rover Evoque Convertible	2016	Diesel I4 2.2L	●
Range Rover Evoque Convertible	2016	GTDI 2.0L	●
Range Rover Evoque Convertible	2016	Diesel I4 2.0L	●
Range Rover Evoque (China)	2016	Diesel I4 2.2L	●
Range Rover Evoque (China)	2016	GTDI 2.0L	●
Range Rover Evoque (China)	2016	Diesel I4 2.0L	●
Range Rover Velar	2018-	V8 5.0L Petrol	●
Range Rover Velar	2018-	V6 3.0L Diesel	●
Range Rover Velar	2018-	204DT 2.0L Diesel	●
Range Rover Velar	2018-	V6 3.0L Petrol	●
Range Rover Velar	2018-	AJ200P 2.0L Petrol	●

OTHER Function List

Active Damping Control Module - Build Mode
Active Damping Control Module - Calibration Learn
Adaptive Speed Control - Speed Control Alignment
Adaptive Speed Control - Speed Control Internal State
Add/remove Accessories - Mirror Personalisation Features
Add/remove Accessories - Passenger Restraint Disable Switch
Add/remove Accessories - Tire Size (Rolling Circumference)
All Wheel Drive - All Wheel Drive - Calibration
All Wheel Drive - All Wheel Drive - System Flush
All Wheel Drive - All Wheel Drive System - Pump Bleed
All Wheel Drive - All Wheel Drive System - Pump Venting
All Wheel Drive - All Wheel Drive System - Transfer Case Control Module Reset - Clear
Audio System - Calibrate Dynamic Volume Control
Auxiliary Heater - Auxiliary Heater Activation Test

Auxiliary Heater - Auxiliary Heater Configuration Check
Auxiliary Heater - Auxiliary Heater Fuel Delivery Test
Body Systems - Crash Status Reset
Powertrain - Engine Control Module Vin Learn Application
Body Systems - Ignition Cycle Counter Reset
Body Systems - Lock Steering Tune To Vehicle
Safety Belt Pretensioner System - Clear Module Learn Data B
Body Systems - Pedestrian Impact Crash Status Reset
Safety Belt Pretensioner System - Driver's Side - Dynamic Safety Belt Retract And
Body Systems - Rain Sensor Calibration
Body Systems - Rain Sensor Initialisation
Safety Belt Pretensioner System - Passenger's Side - Dynamic Safety Belt Retract And
Body Systems - Valet Mode Reset
Car Configuration Management - Fuel Tank Volume
Car Configuration Management - Speed Limitation
Car Configuration Management - Tire Circumference
Clear Module Learn Data A
Deploy Deployable Towbar
Deployable Towbar Recovery
Deployable Towbar Speaker Test
Safety Belt Pretensioner System - Dynamic Safety Belt Retract And Release
Security - Keyfob Remote Functionality
Security - Third Button Configuration
Entertainment System - Dvd Region Counter Reset
Entertainment System - Front Control Display Interface Module - Graphics Update
Entertainment System - InControl Touch Pro Customer Pin Reset
Entertainment System - Navigation Reset
Special Applications - Transportation Mode
Head Up Display - Activate Test Picture
Head Up Display - Head Up Display Control Module Reset
Auxiliary Heater - Auxiliary Heater Priming Routine
Heating And Ventilation - Vent Actuators Test
Image Processing Module Camera's - Camera Auto Learn Routine
Image Processing Module Camera's - Camera Register Update
Instrument Cluster Control Module - Fuel Consumption Units
Instrument Cluster Control Module - Message Centre Display Contrast
Lighting - Automatic High Beam Camera Calibration
Rear Differential Control Module - Control Module Calibration
Running Board Control Module - Service Mode Disabled
Running Board Control Module - Service Mode Enabled
Lighting - Power Module - Reset
Powertrain - Paddle Shift Configuration
Side Object Detection - Side Object Detection Configuration(Left)
Side Object Detection - Side Object Detection Configuration(Right)
Special Applications - Dc To Dc Electric Power Inverter Converter Module Mode
Special Applications - Hybrid Electric Vehicle Operation Mode
Special Applications - Parking Aid Control Module Reset
Special Applications - Parking Aid Control Module Reset Configuration State
Special Applications - Parking Aid Switch-Enable(Disable)
Special Applications - Pre-delivery Inspection
Special Applications - Restraints Build Mode
Stow Deployable Towbar

Unlock Deployable Towbar
All Wheel Drive - All Wheel Drive - High Oil Temperature Reset
Telematics Control Module - Emergency Call And Breakdown Call Switch Illumination Test
Telematics Control Module - Network Registration Status
Telematics Control Module - Pre-activate Telematics Control Module
Telematics Control Module - Reset/clear Wifi Hotspot
Telematics Control Module - Telematics Operational Mode
Telematics Control Module - Telematics Server Communication Check
Telematics Control Module - Telematics Sim Card Type