

BENZ ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Chassis	Model Year	ETC
CLA (117)	ALL	●
124	ALL	●
SL (129)	Up to 08/99	●
SL (129)	As Of 09/99	●
S (140)	ALL	●
GLA (156)	ALL	●
ML (163)	ALL	●
M (164)	ALL	●
GL (164)	ALL	●
ML (166)	ALL	●
GL (166)	ALL	●
A (169)	Up To 11/2005	●
A (169)	As Of 12/2005	●
SLK (170)	16-PIN	●
SLK (170)	38-PIN	●
SLK (171)	Up To 05/2005	●
SLK (171)	As Of 06/2005	●
SLK (172)	ALL	●
A (176)	ALL	●
AMG (190)	ALL	●
SLR (199)	ALL	●
C (202)	Up to 05/97	●
C (202)	As Of 06/97	●
CLC (203)	Up To 08/2003	●
CLC (203)	As Of 09/2003	●
CLC (203)	As Of 01/2008	●
C (204)	ALL	●
GLK (204)	ALL	●
C (205)	ALL	●
E (207)	ALL	●
CLK (208)	ALL	●
CLK (209)	Up To 03/2004	●
CLK (209)	As Of 04/2004	●
E (210)	Up to 02/97	●
E (210)	As Of 03/97	●
E (211)	Up To 05/2005	●
E (211)	From 06/2005 To 05/2006	●
E (211)	As Of 06/2006	●
E (212)	ALL	●
E (213)	ALL	●
CL (215)	Up To 08/2002	●
CL (215)	As Of 09/2002	●
CL (216)	ALL	●
S (217)	ALL	●
CLS (218)	ALL	●
CLS (219)	Up To 05/2005	●
CLS (219)	From 06/2005 To 05/2006	●

CLS (219)	As Of 06/2006	●
S (220)	Up To 08/2002	●
S (220)	As Of 09/2002	●
S (221)	Up To 06/2009	●
S (221)	As Of 07/2009	●
S (222)	ALL	●
SL (230)	Up To 08/2003	●
SL (230)	From 09/2003 To 02/2008	●
SL (230)	AS Of 03/2008	●
SL (231)	ALL	●
E (238)	ALL	●
Maybach (240)	As Of 09/2006	●
B (242)	ALL	●
B (245)	Up To 11/2005	●
B (245)	As Of 12/2005	●
B (246)	ALL	●
R (251)	ALL	●
GLC (253)	ALL	●
M (292)	ALL	●
G (461)	As Of 03/2007 (16-PIN)	●
G (463)	Up To 03/2004 (16-PIN)	●
G (463)	From 04/2004 To 08/2006 (16-PIN)	●
G (463)	From 09/2006 To 02/2007 (16-PIN)	●
G (463)	From 03/2007 To 12/2011 (16-PIN)	●
G (463)	From 01/2012 To 12/2017 (16-PIN)	●
G (463)	38-PIN	●

## ETC Function List

Learning of the throttle valve stop
Replace component M16/6(Throttle valve actuator)
Resetting of adaptation values
Teach In Of Throttle Valve Stop
Teach in component M16/6(Throttle valve actuator)
Teach in component M55 (Inlet port shutoff motor)
Teach in of throttle valve stop
Teach-in Of Intake Port Shutoff
Teach-in of throttle valve end stops of right and left throttle valve actuators
Teach-in of throttle valve stop
Y94 (Quantity Control Valve)