

PEUGEOT BMS Function List (Note:For reference only)

NOTES:

● This function is supported.

\* This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Model Type	BMS
2008		●
207	207 (+)	●
207	207 (CAN)	●
208	208	●
3008	3008	●
3008	3008 (CHINA)	●
3008	3008 (Hybrid4)	●
3008	3008 (P84)	●
301		●
308	308 (2010.01 - 2014.09)	●
308	308 (4 Doors)	●
308	308 (S)	●
308	308 (T9) (2014.10 - )	●
308	308 (TX9)	●
4008	4008 (CHINA)	●
407		●
408	408 (2010.01 - 2014.09)	●
408	408 (T93) (2014.10 - )	●
5008	5008	●
5008	5008 (P84)	●
508	508	●
508	508 (Hybrid4)	●
508	508 (RXH Hybrid4)	●
508	508 (RXH)	●
EXPERT	EXPERT (3)	●
EXPERT	EXPERT (K0)	●
PARTNER	PARTNER (B9)	●
PARTNER	PARTNER Electric (B9E)	●
RCZ		●
TRAVELLER		●

PEUGEOT BMS Function List (Note:For reference only)

Manual Configuration