

PEUGEOT DPF Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Model Type	DPF
1007	1007 (CAN)	●
2008		●
206	206	●
206	206 (Mux)	●
207	207 (CAN)	●
208	208	●
208	208 (Ai91)	●
3008	3008	●
3008	3008 (CHINA)	●
3008	3008 (Hybrid4)	●
3008	3008 (P84)	●
301		●
307	307 (CAN) (2006.01 -)	●
307	307 (VAN) (- 2005.12)	●
308	308 (2010.01 - 2014.09)	●
308	308 (4 Doors)	●
308	308 (S)	●
308	308 (T9) (2014.10 -)	●
4007	4007	●
4008	4008	●
4008	4008 (CHINA)	●
407		●
408	408 (2010.01 - 2014.09)	●
408	408 (T93) (2014.10 -)	●
5008	5008	●
5008	5008 (P84)	●
508	508	●
508	508 (Hybrid4)	●
508	508 (RXH Hybrid4)	●
508	508 (RXH)	●
607	607 (CAN)	●
807	807 (CAN) (2005 -)	●
BOXER	BOXER (3) (Euro 5 / 6)	●
EXPERT	EXPERT (2)	●
EXPERT	EXPERT (3)	●
EXPERT	EXPERT (K0)	●
PARTNER	PARTNER (2) (M69)	●
PARTNER	PARTNER (B9)	●
RCZ		●
TRAVELLER		●
207	207 (+)	●

PEUGEOT DPF Function List (Note:For reference only)

Filling Of The Diesel Additive Adding Reservoir

Forced Regeneration Of The Particle Emission Filter

Forced Regeneration Of The Particle Filter, Vehicle Stationary

Forced Regeneration Of The Particulate Filter While Driving

Forced Regeneration Vehicle Moving

Forced Regeneration Vehicle Stationary

Pariticle Filter Regeneration

Particulate Filter Replacement

Replacement Of The Diesel Additive Reservoir,Of The Pump Or Of The Pipes

Replacement Of The Differential Pressure Sensor

Replacement Of The Particle Emission Filter

Replacement Of The Particle Emission Filter Differential Pressure Sensor