

PEUGEOT ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Model Type	ETC
1007	1007 (CAN)	●
1007	1007 (VAN)	●
2008		●
206	206	●
206	206 (+)	●
206	206 (Mux)	●
207	207 (+)	●
207	207 (CAN)	●
207	207 (i)	●
207	207 (VAN)	●
208	208	●
208	208 (Ai91)	●
3008	3008	●
3008	3008 (CHINA)	●
3008	3008 (Hybrid4)	●
301		●
307	307 (CAN) (2006.01 - )	●
307	307 (VAN) ( - 2005.12)	●
308	308 (2010.01 - 2014.09)	●
308	308 (4 Doors)	●
308	308 (S)	●
308	308 (T9) (2014.10 - )	●
406	406 (R Coupe)	●
406	406 (R)	●
407		●
408	408 (2010.01 - 2014.09)	●
408	408 (T93) (2014.10 - )	●
5008	5008	●
508	508	●
508	508 (Hybrid4)	●
508	508 (RXH Hybrid4)	●
508	508 (RXH)	●
607	607 (CAN)	●
607	607 (VAN)	●
806		●
807	807 (CAN) (2005 - )	●
807	807 (VAN) (2002 - 2005)	●
EXPERT	EXPERT (1)	●
EXPERT	EXPERT (2)	●
EXPERT	EXPERT (3)	●
HOGGAR		●
PARTNER	PARTNER (2)	●
PARTNER	PARTNER (2) (M69)	●
PARTNER	PARTNER (B9)	●
RCZ		●

PEUGEOT ETC Function List (Note:For reference only)

Initialisation Of The EGR Throttle

Initialising The Autoadaptives

Motorised Throttle Unit

Replacement Of Exhaust Gas Recycling Electric Throttle

Throttle Learning