

**PEUGEOT Diagnostic Function List (Note:For reference only)**

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Model Type	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData	Act
1007	1007 (CAN)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
1007	1007 (CAN)	AC (Air Conditioning)	●	●	●	●	●
1007	1007 (CAN)	Alarm	●	●	●	●	●
1007	1007 (CAN)	BSI (Built-in Systems Interface)	●	●	●	●	●
1007	1007 (CAN)	CD (CD Player)	●	●	●	●	●
1007	1007 (CAN)	ECM (Engine Control Module)	●	●	●	●	●
1007	1007 (CAN)	EPS (Electric Power Steering)	●	●	●	●	●
1007	1007 (CAN)	HFC (Hands Free Control Kit)	●	●	●	●	●
1007	1007 (CAN)	IP (Instrument Cluster Panel)	●	●	●	●	●
1007	1007 (CAN)	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
1007	1007 (CAN)	MULD (Multifunction Display)	●	●	●	●	●
1007	1007 (CAN)	PAM (Parking Assistance)	●	●	●	●	●
1007	1007 (CAN)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
1007	1007 (CAN)	Radio	●	●	●	●	●
1007	1007 (CAN)	SRS (Airbag)	●	●	●	●	●
1007	1007 (CAN)	SSDM (Sliding Side Doors Module)	●	●	●	●	●
1007	1007 (CAN)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
1007	1007 (CAN)	TCM (Automatic Gearbox)	●	●	●	●	●
1007	1007 (CAN)	TEU (Telematics Unit)	●	●	●	●	●
1007	1007 (CAN)	UID (Under Inflation Detection)	●	●	●	●	●
1007	1007 (VAN)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
1007	1007 (VAN)	AC (Air Conditioning)	●	●	●	●	●
1007	1007 (VAN)	BSI (Built-in Systems Interface)	●	●	●	●	●
1007	1007 (VAN)	CD (CD Player)	●	●	●	●	●
1007	1007 (VAN)	ECM (Engine Control Module)	●	●	●	●	●
1007	1007 (VAN)	EPS (Electric Power Steering GEP)	●	●	●	●	●
1007	1007 (VAN)	IP (Instrument Cluster Panel)	●	●	●	●	●
1007	1007 (VAN)	MULD (Multifunction Display)	●	●	●	●	●
1007	1007 (VAN)	MULS (Multifunction Screen)	●	●	●	●	●
1007	1007 (VAN)	PAM (Parking Assistance)	●	●	●	●	●
1007	1007 (VAN)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
1007	1007 (VAN)	Radio	●	●	●	●	●
1007	1007 (VAN)	SRS (Airbag)	●	●	●	●	●
1007	1007 (VAN)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
1007	1007 (VAN)	TCM (Automatic Gearbox)	●	●	●	●	●
107		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
107		CAS (Coded Anti-start)	●	●	●	●	●
107		ECM (Engine Control Module)	●	●	●	●	●
107		EPS (Electric Power Steering GEP)	●	●	●	●	●
107		Radio	●	●	●	●	●
107		SRS (Airbag)	●	●	●	●	●
107		TCM (Automatic Gearbox)	●	●	●	●	●
108		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
108		AC (Air Conditioning)	●	●	●	●	●
108		ECM (Engine Control Module)	●	●	●	●	●
108		EPS (Electric Power Steering)	●	●	●	●	●
108		IMMO/HFSM (Engine Immobiliser\Hands Free Starting Access Electric Module)	●	●	●	●	●
108		IP (Instrument Cluster Panel)	●	●	●	●	●
108		MULC/RD (Multifunction Video Camera And Remote Detection By Laser Assembly)	●	●	●	●	●
108		MULS (Multifunction Screen)	●	●	●	●	●
108		SRS (Airbag)	●	●	●	●	●
108		SSC (Stop And Start Control ECU)	●	●	●	●	●
108		TCM (Automatic Gearbox)	●	●	●	●	●

2008		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
2008		AC (Air Conditioning)	●	●	●	●	●
2008		AMP (Audio Amplifier)	●	●	●	●	●
2008		Alarm	●	●	●	●	●
2008		BATT (Battery Charge Status Unit)	●	●	●	●	●
2008		BSI (Built-in Systems Interface)	●	●	●	●	●
2008		CD (External CD Player)	●	●	●	●	●
2008		ECM (Engine Control Module)	●	●	●	●	●
2008		EPS (Electric Power Steering)	●	●	●	●	●
2008		ESL (Electric Steering Lock)	●	●	●	●	●
2008		IP (Instrument Cluster Panel)	●	●	●	●	●
2008		MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
2008		MCP (Multiplexed Control Panel)	●	●	●	●	●
2008		MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
2008		NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
2008		PAM (Parking Assistance)	●	●	●	●	●
2008		RBS (Rain And Brightness Sensor)	●	●	●	●	●
2008		Radio	●	●	●	●	●
2008		SM (Services Module)	●	●	●	●	●
2008		SRS (Airbag)	●	●	●	●	●
2008		SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
2008		SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
2008		Siren	●	●	●	●	●
2008		TCM (Automatic Gearbox)	●	●	●	●	●
2008		TRU (Trailer Relay Unit)	●	●	●	●	●
2008		VRD (Voltage Retaining Device)	●	●	●	●	●
206	206	ABS (Anti-lock brake System TEVES)	●	●	●	●	●
206	206	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
206	206	AC (Air Conditioning)	●	●	●	●	●
206	206	Alarm	●	●	●	●	●
206	206	BSI (Built-in Systems Interface)	●	●	●	●	●
206	206	CD (CD Player)	●	●	●	●	●
206	206	DAF (Diesel Additive Control Unit)	●	●	●	●	●
206	206	DSM (Driver's School Module)	●	●	●	●	●
206	206	Display/Telematics	●	●	●	●	●
206	206	ECM (Engine Control Module)	●	●	●	●	●
206	206	EPS (Electric Power Steering GEP)	●	●	●	●	●
206	206	EPS (Electric Power Steering)	●	●	●	●	●
206	206	ERF (Electric Retractable Roof)	●	●	●	●	●
206	206	IP (Instrument Cluster Panel)	●	●	●	●	●
206	206	MULD (Multifunction Display)	●	●	●	●	●
206	206	MULS (Multifunction Screen)	●	●	●	●	●
206	206	NAVI (On-board Navigation System)	●	●	●	●	●
206	206	RBS (Rain And Brightness Sensor)	●	●	●	●	●
206	206	Radio	●	●	●	●	●
206	206	SM (Services Module)	●	●	●	●	●
206	206	SRS (Airbag)	●	●	●	●	●
206	206	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
206	206	TCM (Automatic Gearbox)	●	●	●	●	●
206	206 (+)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
206	206 (+)	AC (Air Conditioning)	●	●	●	●	●
206	206 (+)	Alarm	●	●	●	●	●
206	206 (+)	BSI (Built-in Systems Interface)	●	●	●	●	●
206	206 (+)	CD (CD Player)	●	●	●	●	●
206	206 (+)	Display/Telematics	●	●	●	●	●
206	206 (+)	ECM (Engine Control Module)	●	●	●	●	●
206	206 (+)	EPS (Electric Power Steering)	●	●	●	●	●
206	206 (+)	IP (Instrument Cluster Panel)	●	●	●	●	●
206	206 (+)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
206	206 (+)	Radio	●	●	●	●	●
206	206 (+)	SM (Services Module)	●	●	●	●	●

206	206 (+)	SRS (Airbag)	●	●	●	●	●
206	206 (+)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
206	206 (+)	TCM (Automatic Gearbox)	●	●	●	●	●
206	206 (Mux)	ABS (Anti-lock brake System TEVES)	●	●	●	●	●
206	206 (Mux)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
206	206 (Mux)	AC (Air Conditioning)	●	●	●	●	●
206	206 (Mux)	Alarm	●	●	●	●	●
206	206 (Mux)	BSI (Built-in Systems Interface)	●	●	●	●	●
206	206 (Mux)	CD (CD Player)	●	●	●	●	●
206	206 (Mux)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
206	206 (Mux)	DSM (Driver's School Module)	●	●	●	●	●
206	206 (Mux)	ECM (Engine Control Module)	●	●	●	●	●
206	206 (Mux)	EPS (Electric Power Steering GEP)	●	●	●	●	●
206	206 (Mux)	ERF (Electric Retractable Roof)	●	●	●	●	●
206	206 (Mux)	IP (Instrument Cluster Panel)	●	●	●	●	●
206	206 (Mux)	MULD (Multifunction Display)	●	●	●	●	●
206	206 (Mux)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
206	206 (Mux)	Radio	●	●	●	●	●
206	206 (Mux)	SRS (Airbag)	●	●	●	●	●
206	206 (Mux)	TCM (Automatic Gearbox)	●	●	●	●	●
207	207 (+)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
207	207 (+)	AC (Air Conditioning)	●	●	●	●	●
207	207 (+)	ALM (Anti-theft Alarm)	●	●	●	●	●
207	207 (+)	BATT (Battery Charge Status Unit)	●	●	●	●	●
207	207 (+)	BSI (Built-in Systems Interface)	●	●	●	●	●
207	207 (+)	CD (CD Player)	●	●	●	●	●
207	207 (+)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
207	207 (+)	DHL (Directional Headlamps)	●	●	●	●	●
207	207 (+)	DSM (Driver's School Module)	●	●	●	●	●
207	207 (+)	ECM (Engine Control Module)	●	●	●	●	●
207	207 (+)	EPS (Electric Power Steering)	●	●	●	●	●
207	207 (+)	FR (Folding Roof)	●	●	●	●	●
207	207 (+)	HFC (Hands Free Control Kit)	●	●	●	●	●
207	207 (+)	HFR (High Frequency Receiver)	●	●	●	●	●
207	207 (+)	IP (Instrument Cluster Panel)	●	●	●	●	●
207	207 (+)	MULD (Multifunction Display)	●	●	●	●	●
207	207 (+)	PAM (Parking Assistance)	●	●	●	●	●
207	207 (+)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
207	207 (+)	ROR (Radio Or Radiotelephone(Radio Part))	●	●	●	●	●
207	207 (+)	SB (Seat Belts Not Fastened LED Unit)	●	●	●	●	●
207	207 (+)	SM (Services Module)	●	●	●	●	●
207	207 (+)	SRS (Airbag)	●	●	●	●	●
207	207 (+)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
207	207 (+)	TCM (Automatic Gearbox)	●	●	●	●	●
207	207 (+)	TEU (Telematics Unit)	●	●	●	●	●
207	207 (+)	UID (Under Inflation Detection)	●	●	●	●	●
207	207 (CAN)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
207	207 (CAN)	AC (Air Conditioning)	●	●	●	●	●
207	207 (CAN)	Alarm	●	●	●	●	●
207	207 (CAN)	BATT (Battery Charge Status Unit)	●	●	●	●	●
207	207 (CAN)	BSI (Built-in Systems Interface)	●	●	●	●	●
207	207 (CAN)	CD (CD Player)	●	●	●	●	●
207	207 (CAN)	DHL (Directional Headlamps)	●	●	●	●	●
207	207 (CAN)	DSM (Driver's School Module)	●	●	●	●	●
207	207 (CAN)	ECM (Engine Control Module)	●	●	●	●	●
207	207 (CAN)	EPS (Electric Power Steering)	●	●	●	●	●
207	207 (CAN)	FR (Folding Roof)	●	●	●	●	●
207	207 (CAN)	HFC (Hands Free Control Kit)	●	●	●	●	●
207	207 (CAN)	HFR (High Frequency Receiver)	●	●	●	●	●
207	207 (CAN)	IP (Instrument Cluster Panel)	●	●	●	●	●
207	207 (CAN)	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●

207	207 (CAN)	MULS (Multifunction Screen)	●	●	●	●	●
207	207 (CAN)	N-TNB (Not Fastened Warning Light (Tnb))	●	●	●	●	●
207	207 (CAN)	PAM (Parking Assistance)	●	●	●	●	●
207	207 (CAN)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
207	207 (CAN)	Radio	●	●	●	●	●
207	207 (CAN)	SM (Services Module)	●	●	●	●	●
207	207 (CAN)	SRS (Airbag)	●	●	●	●	●
207	207 (CAN)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
207	207 (CAN)	TCM (Automatic Gearbox)	●	●	●	●	●
207	207 (CAN)	TEU (Telematics Unit)	●	●	●	●	●
207	207 (CAN)	UID (Under Inflation Detection)	●	●	●	●	●
207	207 (VAN)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
207	207 (VAN)	AC (Air Conditioning)	●	●	●	●	●
207	207 (VAN)	Alarm	●	●	●	●	●
207	207 (VAN)	BSI (Built-in Systems Interface)	●	●	●	●	●
207	207 (VAN)	CD (CD Player)	●	●	●	●	●
207	207 (VAN)	ECM (Engine Control Module)	●	●	●	●	●
207	207 (VAN)	IP (Instrument Cluster Panel)	●	●	●	●	●
207	207 (VAN)	MULD (Multifunction Display)	●	●	●	●	●
207	207 (VAN)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
207	207 (VAN)	Radio	●	●	●	●	●
207	207 (VAN)	SM (Services Module)	●	●	●	●	●
207	207 (VAN)	SRS (Airbag)	●	●	●	●	●
207	207 (VAN)	SVLCU (Stolen Vehicle Location Control)	●	●	●	●	●
207	207 (VAN)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
207	207 (VAN)	TCM (Automatic Gearbox)	●	●	●	●	●
207	207 (VAN)	Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
207	207 (i)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
207	207 (i)	AC (Air Conditioning)	●	●	●	●	●
207	207 (i)	Alarm	●	●	●	●	●
207	207 (i)	BSI (Built-in Systems Interface)	●	●	●	●	●
207	207 (i)	CD (CD Player)	●	●	●	●	●
207	207 (i)	Display/Telematics	●	●	●	●	●
207	207 (i)	ECM (Engine Control Module)	●	●	●	●	●
207	207 (i)	IP (Instrument Cluster Panel)	●	●	●	●	●
207	207 (i)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
207	207 (i)	Radio	●	●	●	●	●
207	207 (i)	SM (Services Module)	●	●	●	●	●
207	207 (i)	SRS (Airbag)	●	●	●	●	●
207	207 (i)	SVLCU (Stolen Vehicle Location Control)	●	●	●	●	●
207	207 (i)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
207	207 (i)	TCM (Automatic Gearbox)	●	●	●	●	●
207	207 (i)	Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
208	208	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
208	208	AC (Air Conditioning)	●	●	●	●	●
208	208	ALM (Anti-theft Alarm)	●	●	●	●	●
208	208	AMP (Audio Amplifier)	●	●	●	●	●
208	208	BATT (Battery Charge Status Unit)	●	●	●	●	●
208	208	BSI (Built-in Systems Interface)	●	●	●	●	●
208	208	CD (CD Player)	●	●	●	●	●
208	208	DSM (Driver's School Module)	●	●	●	●	●
208	208	ECM (Engine Control Module)	●	●	●	●	●
208	208	EPS (Electric Power Steering)	●	●	●	●	●
208	208	IP (Instrument Cluster Panel)	●	●	●	●	●
208	208	LRU (Lighting Relay Unit)	●	●	●	●	●
208	208	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
208	208	MCP (Multiplexed Control Panel)	●	●	●	●	●
208	208	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
208	208	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
208	208	PAM (Parking Assistance)	●	●	●	●	●
208	208	RBS (Rain And Brightness Sensor)	●	●	●	●	●

208	208	Radio	●	●	●	●	●
208	208	SM (Services Module)	●	●	●	●	●
208	208	SRS (Airbag)	●	●	●	●	●
208	208	SWIC (Steering Wheel With Integral Controls)	●	●	●	●	●
208	208	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
208	208	Siren	●	●	●	●	●
208	208	TCM (Automatic Gearbox)	●	●	●	●	●
208	208	TRU (Trailer Relay Unit)	●	●	●	●	●
208	208	VRD (Voltage Retaining Device)	●	●	●	●	●
208	208 (Ai91)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
208	208 (Ai91)	AC (Air Conditioning)	●	●	●	●	●
208	208 (Ai91)	ALM (Anti-theft Alarm)	●	●	●	●	●
208	208 (Ai91)	BSI (Built-in Systems Interface)	●	●	●	●	●
208	208 (Ai91)	CD (External CD Player)	●	●	●	●	●
208	208 (Ai91)	ECM (Engine Control Module)	●	●	●	●	●
208	208 (Ai91)	EPS (Electric Power Steering)	●	●	●	●	●
208	208 (Ai91)	IP (Instrument Cluster Panel)	●	●	●	●	●
208	208 (Ai91)	MCP (Multiplexed Control Panel)	●	●	●	●	●
208	208 (Ai91)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
208	208 (Ai91)	PAM (Parking Assistance)	●	●	●	●	●
208	208 (Ai91)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
208	208 (Ai91)	Radio	●	●	●	●	●
208	208 (Ai91)	SM (Services Module)	●	●	●	●	●
208	208 (Ai91)	SRS (Airbag)	●	●	●	●	●
208	208 (Ai91)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
208	208 (Ai91)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
208	208 (Ai91)	Siren	●	●	●	●	●
208	208 (Ai91)	TCM (Automatic Gearbox)	●	●	●	●	●
208	208 (Ai91)	VRD (Voltage Retaining Device)	●	●	●	●	●
3008	3008	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
3008	3008	AC (Air Conditioning)	●	●	●	●	●
3008	3008	AC (Rear Air Conditioning)	●	●	●	●	●
3008	3008	ALM (Anti-theft Alarm)	●	●	●	●	●
3008	3008	AMP (Audio Amplifier)	●	●	●	●	●
3008	3008	ASM (Anti-slip Mode Selector)	●	●	●	●	●
3008	3008	Alarm	●	●	●	●	●
3008	3008	BATT (Battery Charge Status Unit)	●	●	●	●	●
3008	3008	BATT (Traction Battery ECU)	●	●	●	●	●
3008	3008	BCM (Body Control Module)	●	●	●	●	●
3008	3008	BSI (Built-in Systems Interface)	●	●	●	●	●
3008	3008	CD (CD Player)	●	●	●	●	●
3008	3008	CD (External CD Player)	●	●	●	●	●
3008	3008	CPDMD (Control Panel Dot Matrix Display)	●	●	●	●	●
3008	3008	DAF (Diesel Additive Pump)	●	●	●	●	●
3008	3008	DDC (Driver's Door Control Panel)	●	●	●	●	●
3008	3008	DSC (Driver's Seat Comfort ECU)	●	●	●	●	●
3008	3008	DSP (Driver's Seat Pneumatic Functions ECU)	●	●	●	●	●
3008	3008	Display	●	●	●	●	●
3008	3008	ECM (Engine Control Module)	●	●	●	●	●
3008	3008	EPB (Electric Secondary Brake)	●	●	●	●	●
3008	3008	EPS (Electric Power Steering GEP)	●	●	●	●	●
3008	3008	EPS (Electric Power Steering)	●	●	●	●	●
3008	3008	ERU (Engine Relay Unit)	●	●	●	●	●
3008	3008	ESL (Electric Steering Lock)	●	●	●	●	●
3008	3008	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
3008	3008	HFC (Hands Free Control Kit)	●	●	●	●	●
3008	3008	HFR (High Frequency Receiver)	●	●	●	●	●
3008	3008	HHV (High Head Vision)	●	●	●	●	●
3008	3008	HLH (Headlamp Height Corrector)	●	●	●	●	●
3008	3008	HMS (Hybrid Mode Selector)	●	●	●	●	●
3008	3008	HYC-1 (Hybrid Control ECU 1)	●	●	●	●	●

3008	3008	HYC-2 (Hybrid Control ECU 2)	●	●	●	●	●
3008	3008	IP (Instrument Cluster Panel)	●	●	●	●	●
3008	3008	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
3008	3008	MCP (Multiplexed Control Panel)	●	●	●	●	●
3008	3008	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
3008	3008	MULS (Multifunction Screen)	●	●	●	●	●
3008	3008	N-TNB (Not Fastened Warning Light(Tnb))	●	●	●	●	●
3008	3008	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
3008	3008	NIU (Network Isolation Unit)	●	●	●	●	●
3008	3008	PAM (Parking Assistance)	●	●	●	●	●
3008	3008	PSP (Passenger's Seat Pneumatic Functions ECU)	●	●	●	●	●
3008	3008	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
3008	3008	RBS (Rain And Brightness Sensor)	●	●	●	●	●
3008	3008	RSS (Rain-sunlight Sensor)	●	●	●	●	●
3008	3008	Radio	●	●	●	●	●
3008	3008	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
3008	3008	SHP/VR (Front Left Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
3008	3008	SHP/VR (Front Right Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
3008	3008	SM (Services Module)	●	●	●	●	●
3008	3008	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
3008	3008	SRS (Airbag)	●	●	●	●	●
3008	3008	SWC (Controls On The Steering Wheel)	●	●	●	●	●
3008	3008	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
3008	3008	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
3008	3008	Siren	●	●	●	●	●
3008	3008	TCM (Automatic Gearbox)	●	●	●	●	●
3008	3008	TCM (Sequential Gear Lever)	●	●	●	●	●
3008	3008	TEU (Telematics Unit)	●	●	●	●	●
3008	3008	TRU (Trailer Relay Unit)	●	●	●	●	●
3008	3008	TS (Touch Screen)	●	●	●	●	●
3008	3008	UID (Under Inflation Detection)	●	●	●	●	●
3008	3008	VDA (Vehicle Distance Assistance)	●	●	●	●	●
3008	3008	VRD (Voltage Retaining Device)	●	●	●	●	●
3008	3008	Wiper (Windscreen Wiper)	●	●	●	●	●
3008	3008 (CHINA)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
3008	3008 (CHINA)	AC (Air Conditioning)	●	●	●	●	●
3008	3008 (CHINA)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
3008	3008 (CHINA)	Alarm	●	●	●	●	●
3008	3008 (CHINA)	BATT (Battery Charge Status Unit)	●	●	●	●	●
3008	3008 (CHINA)	BSI (Built-in Systems Interface)	●	●	●	●	●
3008	3008 (CHINA)	DCP (Door Control Pad)	●	●	●	●	●
3008	3008 (CHINA)	ECM (Engine Control Module)	●	●	●	●	●
3008	3008 (CHINA)	EPB (Electric Secondary Brake)	●	●	●	●	●
3008	3008 (CHINA)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
3008	3008 (CHINA)	ERU (Engine Relay Unit)	●	●	●	●	●
3008	3008 (CHINA)	HHV (High Head Vision)	●	●	●	●	●
3008	3008 (CHINA)	IP (Instrument Cluster Panel)	●	●	●	●	●
3008	3008 (CHINA)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
3008	3008 (CHINA)	MULD (Multifunction Display)	●	●	●	●	●
3008	3008 (CHINA)	PAM (Parking Assistance)	●	●	●	●	●
3008	3008 (CHINA)	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
3008	3008 (CHINA)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
3008	3008 (CHINA)	Radio	●	●	●	●	●
3008	3008 (CHINA)	SM (Services Module)	●	●	●	●	●
3008	3008 (CHINA)	SRS (Airbag)	●	●	●	●	●
3008	3008 (CHINA)	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
3008	3008 (CHINA)	TCM (Automatic Gearbox)	●	●	●	●	●
3008	3008 (CHINA)	TEU (Telematics Unit)	●	●	●	●	●
3008	3008 (CHINA)	UID (Under Inflation Detection)	●	●	●	●	●
3008	3008 (CHINA)	VRD (Voltage Retaining Device)	●	●	●	●	●

3008	3008 (CHINA)	Wiper (Windscreen Wiper)	●	●	●	●	●
3008	3008 (Hybrid4)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
3008	3008 (Hybrid4)	AC (Air Conditioning)	●	●	●	●	●
3008	3008 (Hybrid4)	ALM (Anti-theft Alarm)	●	●	●	●	●
3008	3008 (Hybrid4)	AMP (Audio Amplifier)	●	●	●	●	●
3008	3008 (Hybrid4)	BATT (Battery Charge Status Unit)	●	●	●	●	●
3008	3008 (Hybrid4)	BATT (Traction Battery ECU)	●	●	●	●	●
3008	3008 (Hybrid4)	BSI (Built-in Systems Interface)	●	●	●	●	●
3008	3008 (Hybrid4)	CD (CD Player)	●	●	●	●	●
3008	3008 (Hybrid4)	DCP (Door Control Pad)	●	●	●	●	●
3008	3008 (Hybrid4)	ECM (Engine Control Module)	●	●	●	●	●
3008	3008 (Hybrid4)	EPB (Electric Secondary Brake)	●	●	●	●	●
3008	3008 (Hybrid4)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
3008	3008 (Hybrid4)	HFC (Hands Free Control Kit)	●	●	●	●	●
3008	3008 (Hybrid4)	HHV (High Head Vision)	●	●	●	●	●
3008	3008 (Hybrid4)	HMS (Hybrid Mode Selector)	●	●	●	●	●
3008	3008 (Hybrid4)	HYC-1 (Hybrid Control ECU 1)	●	●	●	●	●
3008	3008 (Hybrid4)	HYC-2 (Hybrid Control ECU 2)	●	●	●	●	●
3008	3008 (Hybrid4)	IP (Instrument Cluster Panel)	●	●	●	●	●
3008	3008 (Hybrid4)	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
3008	3008 (Hybrid4)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
3008	3008 (Hybrid4)	MULD (Multifunction Display)	●	●	●	●	●
3008	3008 (Hybrid4)	PAM (Parking Assistance)	●	●	●	●	●
3008	3008 (Hybrid4)	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
3008	3008 (Hybrid4)	RS (Rain Sensor)	●	●	●	●	●
3008	3008 (Hybrid4)	Radio	●	●	●	●	●
3008	3008 (Hybrid4)	SM (Services Module)	●	●	●	●	●
3008	3008 (Hybrid4)	SRS (Airbag)	●	●	●	●	●
3008	3008 (Hybrid4)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
3008	3008 (Hybrid4)	TCM (Automatic Gearbox)	●	●	●	●	●
3008	3008 (Hybrid4)	TEU (Telematics Unit)	●	●	●	●	●
3008	3008 (Hybrid4)	UID (Under Inflation Detection)	●	●	●	●	●
3008	3008 (Hybrid4)	VRD (Voltage Retaining Device)	●	●	●	●	●
3008	3008 (Hybrid4)	Wiper (Windscreen Wiper)	●	●	●	●	●
3008	3008 (P84)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
3008	3008 (P84)	AC (Air Conditioning)	●	●	●	●	●
3008	3008 (P84)	AC (Rear Air Conditioning)	●	●	●	●	●
3008	3008 (P84)	ALM (Anti-theft Alarm)	●	●	●	●	●
3008	3008 (P84)	AMP (Audio Amplifier)	●	●	●	●	●
3008	3008 (P84)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
3008	3008 (P84)	BATT (Battery Charge Status Unit)	●	●	●	●	●
3008	3008 (P84)	BCM (Body Control Module)	●	●	●	●	●
3008	3008 (P84)	BSI (Built-in Systems Interface)	●	●	●	●	●
3008	3008 (P84)	CD (External CD Player)	●	●	●	●	●
3008	3008 (P84)	DAF (Diesel Additive Pump)	●	●	●	●	●
3008	3008 (P84)	DDC (Driver's Door Control Panel)	●	●	●	●	●
3008	3008 (P84)	DHL (Headlamp Height Adjuster/Directional Headlamp)	●	●	●	●	●
3008	3008 (P84)	DSC (Driver's Seat Comfort ECU)	●	●	●	●	●
3008	3008 (P84)	DSP (Driver's Seat Pneumatic Functions ECU)	●	●	●	●	●
3008	3008 (P84)	Display	●	●	●	●	●
3008	3008 (P84)	ECM (Engine Control Module)	●	●	●	●	●
3008	3008 (P84)	EPS (Electric Power Steering)	●	●	●	●	●
3008	3008 (P84)	ERU (Engine Relay Unit)	●	●	●	●	●
3008	3008 (P84)	ESL (Electric Steering Lock)	●	●	●	●	●
3008	3008 (P84)	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
3008	3008 (P84)	IP (Instrument Cluster Panel)	●	●	●	●	●
3008	3008 (P84)	MCP (Multiplexed Control Panel)	●	●	●	●	●
3008	3008 (P84)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
3008	3008 (P84)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
3008	3008 (P84)	PAM (Parking Assistance)	●	●	●	●	●
3008	3008 (P84)	PSP (Passenger's Seat Pneumatic Functions ECU)	●	●	●	●	●

3008	3008 (P84)	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
3008	3008 (P84)	RSS (Rain-sunlight Sensor)	●	●	●	●	●
3008	3008 (P84)	Radio	●	●	●	●	●
3008	3008 (P84)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
3008	3008 (P84)	SHP/VR (Front Left Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
3008	3008 (P84)	SHP/VR (Front Right Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
3008	3008 (P84)	SM (Services Module)	●	●	●	●	●
3008	3008 (P84)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
3008	3008 (P84)	SRS (Airbag)	●	●	●	●	●
3008	3008 (P84)	SWC (Controls On The Steering Wheel)	●	●	●	●	●
3008	3008 (P84)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
3008	3008 (P84)	Siren	●	●	●	●	●
3008	3008 (P84)	TCM (Automatic Gearbox)	●	●	●	●	●
3008	3008 (P84)	TCM (Sequential Gear Lever)	●	●	●	●	●
3008	3008 (P84)	TRU (Trailer Relay Unit)	●	●	●	●	●
3008	3008 (P84)	TS (Touch Screen)	●	●	●	●	●
3008	3008 (P84)	VDA (Vehicle Distance Assistance)	●	●	●	●	●
3008	3008 (P84)	VRD (Voltage Retaining Device)	●	●	●	●	●
3008	3008 (P84)	Wiper (Windscreen Wiper)	●	●	●	●	●
301		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
301		BATT (Battery Charge Status Unit)	●	●	●	●	●
301		BSI (Built-in Systems Interface)	●	●	●	●	●
301		ECM (Engine Control Module)	●	●	●	●	●
301		EPS (Electric Power Steering)	●	●	●	●	●
301		ESL (Electric Steering Lock)	●	●	●	●	●
301		IP (Instrument Cluster Panel)	●	●	●	●	●
301		MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
301		MULS (Multifunction Screen)	●	●	●	●	●
301		NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
301		PAM (Parking Assistance)	●	●	●	●	●
301		Radio	●	●	●	●	●
301		SM (Services Module)	●	●	●	●	●
301		SRS (Airbag)	●	●	●	●	●
301		SWSM (Switch Module At The Steering Wheel)	●	●	●	●	●
301		Siren	●	●	●	●	●
301		TCM (Automatic Gearbox)	●	●	●	●	●
301		TRU (Trailer Relay Unit)	●	●	●	●	●
301		VRD (Voltage Retaining Device)	●	●	●	●	●
306	306	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
306	306	ECM (Engine Control Module)	●	●	●	●	●
306	306	SRS (Airbag)	●	●	●	●	●
306	306	TCM (Automatic Gearbox)	●	●	●	●	●
306	306 (R)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
306	306 (R)	ECM (Engine Control Module)	●	●	●	●	●
306	306 (R)	SRS (Airbag)	●	●	●	●	●
306	306 (R)	TCM (Automatic Gearbox)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	AC (Air Conditioning)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	Alarm	●	●	●	●	●
307	307 (CAN) (2006.01 - )	BSI (Built-in Systems Interface)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	CD (CD Player)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	DAF (Diesel Additive Control Unit)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	DDM (Driver's Door Module)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	DSM (Driver's School Module)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	ECM (Engine Control Module)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	EPS (Electric Power Steering)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	FR (Folding Roof)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	HFC (Hands Free Control Kit)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	HFR (High Frequency Receiver)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	HLLC (Left Headlamp Beam Level Corrector)	●	●	●	●	●



307	307 (CAN) (2006.01 - )	HLRC (Right Headlamp Beam Corrector)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	IP (Instrument Cluster Panel)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	MULS (Multifunction Screen)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	PAM (Parking Assistance)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	PDM (Passenger's Door Module)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	RBS (Rain And Brightness Sensor)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	Radio	●	●	●	●	●
307	307 (CAN) (2006.01 - )	SM (Services Module)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	SRS (Airbag)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	SunRoof	●	●	●	●	●
307	307 (CAN) (2006.01 - )	TCM (Automatic Gearbox)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	TEU (Telematics Unit)	●	●	●	●	●
307	307 (CAN) (2006.01 - )	UID (Under Inflation Detection)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	AC (Air Conditioning)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	Alarm	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	BSI (Built-in Systems Interface)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	CD (CD Player)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	DDM (Driver's Door Module)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	DSM (Driver's School Module)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	ECM (Engine Control Module)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	EPS (Electric Power Steering GEP)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	IP (Instrument Cluster Panel)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	MULD (Multifunction Display)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	PAM (Parking Assistance)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	PDM (Passenger's Door Module)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	Radio	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	SM (Services Module)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	SRS (Airbag)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
307	307 (VAN) ( - 2005.12)	TCM (Automatic Gearbox)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	AC (Air Conditioning)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	AH (Additional Heating)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	ALM (Anti-theft Alarm)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	AMP (Audio Amplifier)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	Alarm	●	●	●	●	●
308	308 (2010.01 - 2014.09)	Alarm Lin	●	●	●	●	●
308	308 (2010.01 - 2014.09)	BATT (Battery Charge Status Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	BSI (Built-in Systems Interface)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	CD (CD Player)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	CD (External CD Player)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	CPDMD (Control Panel Dot Matrix Display)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	DDC (Driver's Door Control Panel)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	DDM (Driver's Door Module)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	DHL (Discharge Bulb With Directional Dipped Headlamp)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	DSM (Driver's School Module)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	ECM (Engine Control Module)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	EPS (Electric Power Steering GEP)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	ERU (Engine Relay Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	ESL (Electric Steering Lock)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	FR (Folding Roof)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	HFC (Hands Free Control Kit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	HFR (High Frequency Receiver)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	IP (Instrument Cluster Panel)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	KEY (Electronic Key Reader)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	LDWS (Lane Departure Warning System)	●	●	●	●	●

308	308 (2010.01 - 2014.09)	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	MCP (Multiplexed Control Panel)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	MPD (Moving Panel Deflector)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
308	308 (2010.01 - 2014.09)	MULD (Multifunction Display)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	MULS (Multifunction Screen)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	N-TNB (Not Fastened Warning Light(Tnb))	●	●	●	●	●
308	308 (2010.01 - 2014.09)	NAVI (Telematic Navigator)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	PAM (Parking Assistance)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	PSM (Passenger's Seat Memorizing Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	Radio	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SM (Services Module)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SRS (Airbag)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	Siren	●	●	●	●	●
308	308 (2010.01 - 2014.09)	SunRoof	●	●	●	●	●
308	308 (2010.01 - 2014.09)	TCM (Automatic Gearbox)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	TCM (Sequential Gear Lever)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	TEU (Telematics Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	TRU (Trailer Relay Unit)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	UID (Under Inflation Detection)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	VDA (Vehicle Distance Assistance)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	VRD (Voltage Retaining Device)	●	●	●	●	●
308	308 (2010.01 - 2014.09)	Wiper (Windscreen Wiper)	●	●	●	●	●
308	308 (4 Doors)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
308	308 (4 Doors)	AC (Air Conditioning)	●	●	●	●	●
308	308 (4 Doors)	AMP (Audio Amplifier)	●	●	●	●	●
308	308 (4 Doors)	Alarm	●	●	●	●	●
308	308 (4 Doors)	Alarm Lin	●	●	●	●	●
308	308 (4 Doors)	BATT (Battery Charge Status Unit)	●	●	●	●	●
308	308 (4 Doors)	BSI (Built-in Systems Interface)	●	●	●	●	●
308	308 (4 Doors)	CD (CD Player)	●	●	●	●	●
308	308 (4 Doors)	DCP (Door Control Pad)	●	●	●	●	●
308	308 (4 Doors)	DHL (Directional Headlamps)	●	●	●	●	●
308	308 (4 Doors)	DSM (Driver's School Module)	●	●	●	●	●
308	308 (4 Doors)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
308	308 (4 Doors)	ECM (Engine Control Module)	●	●	●	●	●
308	308 (4 Doors)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
308	308 (4 Doors)	ERU (Engine Relay Unit)	●	●	●	●	●
308	308 (4 Doors)	FR (Folding Roof)	●	●	●	●	●
308	308 (4 Doors)	HFC (Hands Free Control Kit)	●	●	●	●	●
308	308 (4 Doors)	IP (Instrument Cluster Panel)	●	●	●	●	●
308	308 (4 Doors)	LDWS (Lane Departure Warning System)	●	●	●	●	●
308	308 (4 Doors)	MPD (Moving Panel Deflector)	●	●	●	●	●
308	308 (4 Doors)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
308	308 (4 Doors)	MULD (Multifunction Display)	●	●	●	●	●
308	308 (4 Doors)	PAM (Parking Assistance)	●	●	●	●	●
308	308 (4 Doors)	PSM (Passenger's Seat Memorisation Unit)	●	●	●	●	●
308	308 (4 Doors)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
308	308 (4 Doors)	SB (Seat Belts Not Fastened LED Unit)	●	●	●	●	●
308	308 (4 Doors)	SM (Services Module)	●	●	●	●	●
308	308 (4 Doors)	SRS (Airbag)	●	●	●	●	●
308	308 (4 Doors)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
308	308 (4 Doors)	SunRoof	●	●	●	●	●

308	308 (4 Doors)	TCM (Automatic Gearbox)	●	●	●	●	●
308	308 (4 Doors)	TEU (Telematics Unit)	●	●	●	●	●
308	308 (4 Doors)	UID (Under Inflation Detection)	●	●	●	●	●
308	308 (4 Doors)	VRD (Voltage Retaining Device)	●	●	●	●	●
308	308 (4 Doors)	Wiper (Windscreen Wiper)	●	●	●	●	●
308	308 (S)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
308	308 (S)	AC (Air Conditioning)	●	●	●	●	●
308	308 (S)	Alarm	●	●	●	●	●
308	308 (S)	BATT (Battery Charge Status Unit)	●	●	●	●	●
308	308 (S)	BSI (Built-in Systems Interface)	●	●	●	●	●
308	308 (S)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
308	308 (S)	ECM (Engine Control Module)	●	●	●	●	●
308	308 (S)	EPS (Electric Power Steering GEP)	●	●	●	●	●
308	308 (S)	ERU (Engine Relay Unit)	●	●	●	●	●
308	308 (S)	ESL (Electric Steering Lock)	●	●	●	●	●
308	308 (S)	HFC (Hands Free Control Kit)	●	●	●	●	●
308	308 (S)	HLH (Headlamp Height Corrector)	●	●	●	●	●
308	308 (S)	IP (Instrument Cluster Panel)	●	●	●	●	●
308	308 (S)	KEY (Electronic Key Reader)	●	●	●	●	●
308	308 (S)	MCP (Multiplexed Control Panel)	●	●	●	●	●
308	308 (S)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
308	308 (S)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
308	308 (S)	MULD (Multifunction Display)	●	●	●	●	●
308	308 (S)	MULS (Multifunction Screen)	●	●	●	●	●
308	308 (S)	NAVI (Telematic Navigator)	●	●	●	●	●
308	308 (S)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
308	308 (S)	PAM (Parking Assistance)	●	●	●	●	●
308	308 (S)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
308	308 (S)	Radio	●	●	●	●	●
308	308 (S)	SM (Services Module)	●	●	●	●	●
308	308 (S)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
308	308 (S)	SRS (Airbag)	●	●	●	●	●
308	308 (S)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
308	308 (S)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
308	308 (S)	TCM (Automatic Gearbox)	●	●	●	●	●
308	308 (S)	TCM (Sequential Gear Lever)	●	●	●	●	●
308	308 (S)	VRD (Voltage Retaining Device)	●	●	●	●	●
308	308 (T9) (2014.10 - )	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
308	308 (T9) (2014.10 - )	AC (Air Conditioning)	●	●	●	●	●
308	308 (T9) (2014.10 - )	AH (Additional Heating)	●	●	●	●	●
308	308 (T9) (2014.10 - )	ALM (Anti-theft Alarm)	●	●	●	●	●
308	308 (T9) (2014.10 - )	AMP (Audio Amplifier)	●	●	●	●	●
308	308 (T9) (2014.10 - )	BATT (Battery Charge Status Unit)	●	●	●	●	●
308	308 (T9) (2014.10 - )	BSI (Built-in Systems Interface)	●	●	●	●	●
308	308 (T9) (2014.10 - )	CD (External CD Player)	●	●	●	●	●
308	308 (T9) (2014.10 - )	DDC (Driver's Door Control Panel)	●	●	●	●	●
308	308 (T9) (2014.10 - )	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
308	308 (T9) (2014.10 - )	ECM (Engine Control Module)	●	●	●	●	●
308	308 (T9) (2014.10 - )	EPS (Electric Power Steering GEP)	●	●	●	●	●
308	308 (T9) (2014.10 - )	ERU (Engine Relay Unit)	●	●	●	●	●
308	308 (T9) (2014.10 - )	ESL (Electric Steering Lock)	●	●	●	●	●
308	308 (T9) (2014.10 - )	HFC (Hands Free Control Kit)	●	●	●	●	●
308	308 (T9) (2014.10 - )	HLH (Headlamp Height Corrector)	●	●	●	●	●
308	308 (T9) (2014.10 - )	IP (Instrument Cluster Panel)	●	●	●	●	●
308	308 (T9) (2014.10 - )	KEY (Electronic Key Reader)	●	●	●	●	●
308	308 (T9) (2014.10 - )	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
308	308 (T9) (2014.10 - )	MCP (Multiplexed Control Panel)	●	●	●	●	●
308	308 (T9) (2014.10 - )	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
308	308 (T9) (2014.10 - )	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
308	308 (T9) (2014.10 - )	MULD (Multifunction Display)	●	●	●	●	●
308	308 (T9) (2014.10 - )	MULS (Multifunction Screen)	●	●	●	●	●

308	308 (T9) (2014.10 - )	NAVI (Telematic Navigator)	●	●	●	●	●
308	308 (T9) (2014.10 - )	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
308	308 (T9) (2014.10 - )	PAM (Parking Assistance)	●	●	●	●	●
308	308 (T9) (2014.10 - )	RBS (Rain And Brightness Sensor)	●	●	●	●	●
308	308 (T9) (2014.10 - )	Radio	●	●	●	●	●
308	308 (T9) (2014.10 - )	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
308	308 (T9) (2014.10 - )	SM (Services Module)	●	●	●	●	●
308	308 (T9) (2014.10 - )	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
308	308 (T9) (2014.10 - )	SRS (Airbag)	●	●	●	●	●
308	308 (T9) (2014.10 - )	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
308	308 (T9) (2014.10 - )	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
308	308 (T9) (2014.10 - )	Siren	●	●	●	●	●
308	308 (T9) (2014.10 - )	TCM (Automatic Gearbox)	●	●	●	●	●
308	308 (T9) (2014.10 - )	TCM (Sequential Gear Lever)	●	●	●	●	●
308	308 (T9) (2014.10 - )	TRU (Trailer Relay Unit)	●	●	●	●	●
308	308 (T9) (2014.10 - )	VDA (Vehicle Distance Assistance)	●	●	●	●	●
308	308 (T9) (2014.10 - )	VRD (Voltage Retaining Device)	●	●	●	●	●
308	308 (TX9)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
308	308 (TX9)	AC (Air Conditioning)	●	●	●	●	●
308	308 (TX9)	BATT (Battery Charge Status Unit)	●	●	●	●	●
308	308 (TX9)	BSI (Built-in Systems Interface)	●	●	●	●	●
308	308 (TX9)	ECM (Engine Control Module)	●	●	●	●	●
308	308 (TX9)	EPS (Electric Power Steering)	●	●	●	●	●
308	308 (TX9)	ESL (Electric Steering Lock)	●	●	●	●	●
308	308 (TX9)	IP (Instrument Cluster Panel)	●	●	●	●	●
308	308 (TX9)	MCP (Multiplexed Control Panel)	●	●	●	●	●
308	308 (TX9)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
308	308 (TX9)	MULS (Multifunction Screen)	●	●	●	●	●
308	308 (TX9)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
308	308 (TX9)	PAM (Parking Assistance)	●	●	●	●	●
308	308 (TX9)	RSS (Rain-sunlight Sensor)	●	●	●	●	●
308	308 (TX9)	Radio	●	●	●	●	●
308	308 (TX9)	SM (Services Module)	●	●	●	●	●
308	308 (TX9)	SRS (Airbag)	●	●	●	●	●
308	308 (TX9)	SWC (Controls On The Steering Wheel)	●	●	●	●	●
308	308 (TX9)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
308	308 (TX9)	TCM (Automatic Gearbox)	●	●	●	●	●
308	308 (TX9)	VRD (Voltage Retaining Device)	●	●	●	●	●
4007	4007	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
4007	4007	AC (Air Conditioning)	●	●	●	●	●
4007	4007	BSI (Built-in Systems Interface)	●	●	●	●	●
4007	4007	CAS (Coded Anti-start)	●	●	●	●	●
4007	4007	DDM (Driver's Door Module)	●	●	●	●	●
4007	4007	DHL (Headlamp Height Adjuster/Directional Headlamp)	●	●	●	●	●
4007	4007	DPCRf (Rear Final Drive Piloted Clutch)	●	●	●	●	●
4007	4007	DSPRLH (Rear LH Door Switch Panel)	●	●	●	●	●
4007	4007	DSPRRH (Rear RH Door Switch Panel)	●	●	●	●	●
4007	4007	ECM (Engine Control Module)	●	●	●	●	●
4007	4007	HFC (Hands Free Control Kit)	●	●	●	●	●
4007	4007	IP (Instrument Cluster Panel)	●	●	●	●	●
4007	4007	NAVI (Navigation)	●	●	●	●	●
4007	4007	PAM (Parking Assistance)	●	●	●	●	●
4007	4007	PDM (Passenger's Door Module)	●	●	●	●	●
4007	4007	Radio	●	●	●	●	●
4007	4007	SAS (Flywheel Angle Sensor)	●	●	●	●	●
4007	4007	SRS (Airbag)	●	●	●	●	●
4007	4007	SunRoof	●	●	●	●	●
4007	4007	TCM (Automatic Gearbox)	●	●	●	●	●
4007	4007	TCM (Gear Lever(Dct))	●	●	●	●	●
4008	4008	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
4008	4008	AC (Air Conditioning)	●	●	●	●	●

4008	4008	AC (Rear Air Conditioning)	●	●	●	●	●
4008	4008	ALM (Anti-theft Alarm)	●	●	●	●	●
4008	4008	ASM (Anti-slip Mode Selector)	●	●	●	●	●
4008	4008	AUTH (Starting Authorisation ECU)	●	●	●	●	●
4008	4008	BATT (Battery Charge Status Unit)	●	●	●	●	●
4008	4008	BCM (Body Control Module)	●	●	●	●	●
4008	4008	BSI (Built-in Systems Interface)	●	●	●	●	●
4008	4008	CAS/HFCU (Coded Anti-start/Hands-free Control Unit)	●	●	●	●	●
4008	4008	CD (External CD Player)	●	●	●	●	●
4008	4008	DAF (Diesel Additive Pump)	●	●	●	●	●
4008	4008	DDC (Driver's Door Control Panel)	●	●	●	●	●
4008	4008	DHL (Headlamp Height Adjuster/Directional Headlamp)	●	●	●	●	●
4008	4008	DPCRf (Rear Final Drive Piloted Clutch)	●	●	●	●	●
4008	4008	DSC (Driver's Seat Comfort ECU)	●	●	●	●	●
4008	4008	DSP (Driver's Seat Pneumatic Functions ECU)	●	●	●	●	●
4008	4008	Display	●	●	●	●	●
4008	4008	ECM (Engine Control Module)	●	●	●	●	●
4008	4008	EPS (Electric Power Steering)	●	●	●	●	●
4008	4008	ERU (Engine Relay Unit)	●	●	●	●	●
4008	4008	ESL (Electric Steering Lock)	●	●	●	●	●
4008	4008	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
4008	4008	IP (Instrument Cluster Panel)	●	●	●	●	●
4008	4008	MCP (Multiplexed Control Panel)	●	●	●	●	●
4008	4008	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
4008	4008	NAVI (Navigation)	●	●	●	●	●
4008	4008	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
4008	4008	PAM (Parking Assistance)	●	●	●	●	●
4008	4008	PSP (Passenger's Seat Pneumatic Functions ECU)	●	●	●	●	●
4008	4008	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
4008	4008	ROR (Radio Or Radiotelephone(Radio Part))	●	●	●	●	●
4008	4008	RSS (Rain-sunlight Sensor)	●	●	●	●	●
4008	4008	Radio	●	●	●	●	●
4008	4008	SAS (Steering Wheel Angle Sensor)	●	●	●	●	●
4008	4008	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
4008	4008	SHP/VR (Front Left Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
4008	4008	SHP/VR (Front Right Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
4008	4008	SM (Services Module)	●	●	●	●	●
4008	4008	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
4008	4008	SRS (Airbag)	●	●	●	●	●
4008	4008	SSC (Stop And Start Control ECU)	●	●	●	●	●
4008	4008	SWC (Controls On The Steering Wheel)	●	●	●	●	●
4008	4008	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
4008	4008	Siren	●	●	●	●	●
4008	4008	TCM (Automatic Gearbox)	●	●	●	●	●
4008	4008	TCM (Sequential Gear Lever)	●	●	●	●	●
4008	4008	TRU (Trailer Relay Unit)	●	●	●	●	●
4008	4008	TS (Touch Screen)	●	●	●	●	●
4008	4008	VDA (Vehicle Distance Assistance)	●	●	●	●	●
4008	4008	VRD (Voltage Retaining Device)	●	●	●	●	●
4008	4008	Wiper (Windscreen Wiper)	●	●	●	●	●
4008	4008 (CHINA)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
4008	4008 (CHINA)	AC (Air Conditioning)	●	●	●	●	●
4008	4008 (CHINA)	AC (Rear Air Conditioning)	●	●	●	●	●
4008	4008 (CHINA)	ALM (Anti-theft Alarm)	●	●	●	●	●
4008	4008 (CHINA)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
4008	4008 (CHINA)	BATT (Battery Charge Status Unit)	●	●	●	●	●
4008	4008 (CHINA)	BCM (Body Control Module)	●	●	●	●	●
4008	4008 (CHINA)	BSI (Built-in Systems Interface)	●	●	●	●	●
4008	4008 (CHINA)	CD (External CD Player)	●	●	●	●	●
4008	4008 (CHINA)	DAF (Diesel Additive Pump)	●	●	●	●	●

4008	4008 (CHINA)	DDC (Driver's Door Control Panel)	●	●	●	●	●
4008	4008 (CHINA)	DHL (Headlamp Height Adjuster/Directional Headlamp)	●	●	●	●	●
4008	4008 (CHINA)	DSC (Driver's Seat Comfort ECU)	●	●	●	●	●
4008	4008 (CHINA)	DSP (Driver's Seat Pneumatic Functions ECU)	●	●	●	●	●
4008	4008 (CHINA)	Display	●	●	●	●	●
4008	4008 (CHINA)	ECM (Engine Control Module)	●	●	●	●	●
4008	4008 (CHINA)	EPS (Electric Power Steering)	●	●	●	●	●
4008	4008 (CHINA)	ERU (Engine Relay Unit)	●	●	●	●	●
4008	4008 (CHINA)	ESL (Electric Steering Lock)	●	●	●	●	●
4008	4008 (CHINA)	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
4008	4008 (CHINA)	IP (Instrument Cluster Panel)	●	●	●	●	●
4008	4008 (CHINA)	MCP (Multiplexed Control Panel)	●	●	●	●	●
4008	4008 (CHINA)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
4008	4008 (CHINA)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
4008	4008 (CHINA)	PAM (Parking Assistance)	●	●	●	●	●
4008	4008 (CHINA)	PSP (Passenger's Seat Pneumatic Functions ECU)	●	●	●	●	●
4008	4008 (CHINA)	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
4008	4008 (CHINA)	RSS (Rain-sunlight Sensor)	●	●	●	●	●
4008	4008 (CHINA)	Radio	●	●	●	●	●
4008	4008 (CHINA)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
4008	4008 (CHINA)	SHP/VR (Front Left Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
4008	4008 (CHINA)	SHP/VR (Front Right Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
4008	4008 (CHINA)	SM (Services Module)	●	●	●	●	●
4008	4008 (CHINA)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
4008	4008 (CHINA)	SRS (Airbag)	●	●	●	●	●
4008	4008 (CHINA)	SWC (Controls On The Steering Wheel)	●	●	●	●	●
4008	4008 (CHINA)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
4008	4008 (CHINA)	Siren	●	●	●	●	●
4008	4008 (CHINA)	TCM (Automatic Gearbox)	●	●	●	●	●
4008	4008 (CHINA)	TCM (Sequential Gear Lever)	●	●	●	●	●
4008	4008 (CHINA)	TRU (Trailer Relay Unit)	●	●	●	●	●
4008	4008 (CHINA)	TS (Touch Screen)	●	●	●	●	●
4008	4008 (CHINA)	VDA (Vehicle Distance Assistance)	●	●	●	●	●
4008	4008 (CHINA)	VRD (Voltage Retaining Device)	●	●	●	●	●
4008	4008 (CHINA)	Wiper (Windscreen Wiper)	●	●	●	●	●
406	406	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
406	406	AC (Air Conditioning)	●	●	●	●	●
406	406	Alarm	●	●	●	●	●
406	406	BSI (Built-in Systems Interface)	●	●	●	●	●
406	406	CD (CD Player)	●	●	●	●	●
406	406	DAF (Diesel Additive Control Unit)	●	●	●	●	●
406	406	ECM (Engine Control Module)	●	●	●	●	●
406	406	IP (Instrument Cluster Panel)	●	●	●	●	●
406	406	MULS (Multifunction Screen)	●	●	●	●	●
406	406	NAVI (On-board Navigation System)	●	●	●	●	●
406	406	RBS (Rain And Brightness Sensor)	●	●	●	●	●
406	406	Radio	●	●	●	●	●
406	406	SRS (Airbag)	●	●	●	●	●
406	406	SSP (Electronically Managed Suspension)	●	●	●	●	●
406	406	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
406	406	TCM (Automatic Gearbox)	●	●	●	●	●
406	406 (Coupe)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
406	406 (Coupe)	ECM (Engine Control Module)	●	●	●	●	●
406	406 (Coupe)	SRS (Airbag)	●	●	●	●	●
406	406 (Coupe)	TCM (Automatic Gearbox)	●	●	●	●	●
406	406 (R Coupe)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
406	406 (R Coupe)	AC (Air Conditioning)	●	●	●	●	●
406	406 (R Coupe)	Alarm	●	●	●	●	●
406	406 (R Coupe)	BSI (Built-in Systems Interface)	●	●	●	●	●
406	406 (R Coupe)	CD (CD Player)	●	●	●	●	●

406	406 (R Coupe)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
406	406 (R Coupe)	ECM (Engine Control Module)	●	●	●	●	●
406	406 (R Coupe)	IP (Instrument Cluster Panel)	●	●	●	●	●
406	406 (R Coupe)	MULS (Multifunction Screen)	●	●	●	●	●
406	406 (R Coupe)	NAVI (On-board Navigation System)	●	●	●	●	●
406	406 (R Coupe)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
406	406 (R Coupe)	Radio	●	●	●	●	●
406	406 (R Coupe)	SRS (Airbag)	●	●	●	●	●
406	406 (R Coupe)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
406	406 (R Coupe)	TCM (Automatic Gearbox)	●	●	●	●	●
406	406 (R)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
406	406 (R)	AC (Air Conditioning)	●	●	●	●	●
406	406 (R)	Alarm	●	●	●	●	●
406	406 (R)	BSI (Built-in Systems Interface)	●	●	●	●	●
406	406 (R)	CD (CD Player)	●	●	●	●	●
406	406 (R)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
406	406 (R)	ECM (Engine Control Module)	●	●	●	●	●
406	406 (R)	IP (Instrument Cluster Panel)	●	●	●	●	●
406	406 (R)	MULS (Multifunction Screen)	●	●	●	●	●
406	406 (R)	NAVI (On-board Navigation System)	●	●	●	●	●
406	406 (R)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
406	406 (R)	Radio	●	●	●	●	●
406	406 (R)	SRS (Airbag)	●	●	●	●	●
406	406 (R)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
406	406 (R)	TCM (Automatic Gearbox)	●	●	●	●	●
407		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
407		AC (Air Conditioning)	●	●	●	●	●
407		AH (Additional Heating)	●	●	●	●	●
407		Alarm	●	●	●	●	●
407		BATT (Battery Charge Status Unit)	●	●	●	●	●
407		BSI (Built-in Systems Interface)	●	●	●	●	●
407		BW (Boot Wiring)	●	●	●	●	●
407		CD (CD Player)	●	●	●	●	●
407		DAF (Diesel Additive Control Unit)	●	●	●	●	●
407		DDM (Driver's Door Module)	●	●	●	●	●
407		DHL (Directional Headlamps)	●	●	●	●	●
407		DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
407		ECM (Engine Control Module)	●	●	●	●	●
407		EPS (Electric Power Steering)	●	●	●	●	●
407		HFC (Hands Free Control Kit)	●	●	●	●	●
407		HFR (High Frequency Receiver)	●	●	●	●	●
407		HLLC (Left Headlamp Beam Level Corrector)	●	●	●	●	●
407		HLRC (Right Headlamp Beam Corrector)	●	●	●	●	●
407		IP (Instrument Cluster Panel)	●	●	●	●	●
407		MULD (Multifunction Display)	●	●	●	●	●
407		PAM (Parking Assistance)	●	●	●	●	●
407		PDM (Passenger's Door Module)	●	●	●	●	●
407		PSM (Passenger's Seat Memorizing Unit)	●	●	●	●	●
407		RBS (Rain And Brightness Sensor)	●	●	●	●	●
407		Radio	●	●	●	●	●
407		SRS (Airbag)	●	●	●	●	●
407		SSP (Electronically Managed Suspension)	●	●	●	●	●
407		SWSM (Steering Wheel Switching Module)	●	●	●	●	●
407		SunRoof	●	●	●	●	●
407		TCM (Automatic Gearbox)	●	●	●	●	●
407		TEU (Telematics Unit)	●	●	●	●	●
407		UID (Under Inflation Detection)	●	●	●	●	●
407		Wiper (Windscreen Wiper)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	AC (Air Conditioning)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	AMP (Audio Amplifier)	●	●	●	●	●

408	408 (2010.01 - 2014.09)	Alarm	●	●	●	●	●
408	408 (2010.01 - 2014.09)	Alarm Lin	●	●	●	●	●
408	408 (2010.01 - 2014.09)	BATT (Battery Charge Status Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	BSI (Built-in Systems Interface)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	CD (CD Player)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	DDM (Driver's Door Module)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	DHL (Discharge Bulb With Directional Dipped Headlamp)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	DSM (Driver's School Module)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	ECM (Engine Control Module)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	EPS (Electric Power Steering GEP)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	EPS (Electric Power Steering)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	ERU (Engine Relay Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	ESL (Electric Steering Lock)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	FR (Folding Roof)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	HFC (Hands Free Control Kit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	HFR (High Frequency Receiver)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	IP (Instrument Cluster Panel)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	KEY (Electronic Key Reader)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	LDWS (Lane Departure Warning System)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MCP (Multiplexed Control Panel)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MPD (Moving Panel Deflector)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MULD (Multifunction Display)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	MULS (Multifunction Screen)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	N-TNB (Not Fastened Warning Light (Tnb))	●	●	●	●	●
408	408 (2010.01 - 2014.09)	NAVI (Telematic Navigator)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	PAM (Parking Assistance)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	PSM (Passenger's Seat Memorizing Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	Radio	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SM (Services Module)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SRS (Airbag)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	SunRoof	●	●	●	●	●
408	408 (2010.01 - 2014.09)	TCM (Automatic Gearbox)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	TCM (Sequential Gear Lever)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	TEU (Telematics Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	TRU (Trailer Relay Unit)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	UID (Under Inflation Detection)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	VRD (Voltage Retaining Device)	●	●	●	●	●
408	408 (2010.01 - 2014.09)	Wiper (Windscreen Wiper)	●	●	●	●	●
408	408 (T93) (2014.10 - )	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
408	408 (T93) (2014.10 - )	AC (Air Conditioning)	●	●	●	●	●
408	408 (T93) (2014.10 - )	Alarm	●	●	●	●	●
408	408 (T93) (2014.10 - )	BATT (Battery Charge Status Unit)	●	●	●	●	●
408	408 (T93) (2014.10 - )	BSI (Built-in Systems Interface)	●	●	●	●	●
408	408 (T93) (2014.10 - )	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
408	408 (T93) (2014.10 - )	ECM (Engine Control Module)	●	●	●	●	●
408	408 (T93) (2014.10 - )	EPS (Electric Power Steering GEP)	●	●	●	●	●
408	408 (T93) (2014.10 - )	ERU (Engine Relay Unit)	●	●	●	●	●
408	408 (T93) (2014.10 - )	ESL (Electric Steering Lock)	●	●	●	●	●
408	408 (T93) (2014.10 - )	HFC (Hands Free Control Kit)	●	●	●	●	●
408	408 (T93) (2014.10 - )	HLH (Headlamp Height Corrector)	●	●	●	●	●
408	408 (T93) (2014.10 - )	IP (Instrument Cluster Panel)	●	●	●	●	●



408	408 (T93) (2014.10 - )	KEY (Electronic Key Reader)	●	●	●	●	●
408	408 (T93) (2014.10 - )	MCP (Multiplexed Control Panel)	●	●	●	●	●
408	408 (T93) (2014.10 - )	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
408	408 (T93) (2014.10 - )	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
408	408 (T93) (2014.10 - )	MULD (Multifunction Display)	●	●	●	●	●
408	408 (T93) (2014.10 - )	MULS (Multifunction Screen)	●	●	●	●	●
408	408 (T93) (2014.10 - )	NAVI (Telematic Navigator)	●	●	●	●	●
408	408 (T93) (2014.10 - )	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
408	408 (T93) (2014.10 - )	PAM (Parking Assistance)	●	●	●	●	●
408	408 (T93) (2014.10 - )	RBS (Rain And Brightness Sensor)	●	●	●	●	●
408	408 (T93) (2014.10 - )	Radio	●	●	●	●	●
408	408 (T93) (2014.10 - )	SM (Services Module)	●	●	●	●	●
408	408 (T93) (2014.10 - )	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
408	408 (T93) (2014.10 - )	SRS (Airbag)	●	●	●	●	●
408	408 (T93) (2014.10 - )	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
408	408 (T93) (2014.10 - )	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
408	408 (T93) (2014.10 - )	TCM (Automatic Gearbox)	●	●	●	●	●
408	408 (T93) (2014.10 - )	TCM (Sequential Gear Lever)	●	●	●	●	●
408	408 (T93) (2014.10 - )	VRD (Voltage Retaining Device)	●	●	●	●	●
5008	5008	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
5008	5008	AC (Air Conditioning)	●	●	●	●	●
5008	5008	AC (Rear Air Conditioning)	●	●	●	●	●
5008	5008	ALM (Anti-theft Alarm)	●	●	●	●	●
5008	5008	AMP (Audio Amplifier)	●	●	●	●	●
5008	5008	ASM (Anti-slip Mode Selector)	●	●	●	●	●
5008	5008	Alarm	●	●	●	●	●
5008	5008	BATT (Battery Charge Status Unit)	●	●	●	●	●
5008	5008	BCM (Body Control Module)	●	●	●	●	●
5008	5008	BSI (Built-in Systems Interface)	●	●	●	●	●
5008	5008	CD (CD Player)	●	●	●	●	●
5008	5008	CD (External CD Player)	●	●	●	●	●
5008	5008	CPDMD (Control Panel Dot Matrix Display)	●	●	●	●	●
5008	5008	DAF (Diesel Additive Pump)	●	●	●	●	●
5008	5008	DDC (Driver's Door Control Panel)	●	●	●	●	●
5008	5008	DSC (Driver's Seat Comfort ECU)	●	●	●	●	●
5008	5008	DSP (Driver's Seat Pneumatic Functions ECU)	●	●	●	●	●
5008	5008	Display	●	●	●	●	●
5008	5008	ECM (Engine Control Module)	●	●	●	●	●
5008	5008	EPB (Electric Secondary Brake)	●	●	●	●	●
5008	5008	EPS (Electric Power Steering)	●	●	●	●	●
5008	5008	ERU (Engine Relay Unit)	●	●	●	●	●
5008	5008	ESL (Electric Steering Lock)	●	●	●	●	●
5008	5008	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
5008	5008	HFC (Hands Free Control Kit)	●	●	●	●	●
5008	5008	HFR (High Frequency Receiver)	●	●	●	●	●
5008	5008	HHV (High Head Vision)	●	●	●	●	●
5008	5008	HLH (Headlamp Height Corrector)	●	●	●	●	●
5008	5008	IP (Instrument Cluster Panel)	●	●	●	●	●
5008	5008	LDWS (Lane Departure Warning System)	●	●	●	●	●
5008	5008	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
5008	5008	MCP (Multiplexed Control Panel)	●	●	●	●	●
5008	5008	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
5008	5008	MULS (Multifunction Screen)	●	●	●	●	●
5008	5008	N-TNB (Not Fastened Warning Light(Tnb))	●	●	●	●	●
5008	5008	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
5008	5008	NIU (Network Isolation Unit)	●	●	●	●	●
5008	5008	PAM (Parking Assistance)	●	●	●	●	●
5008	5008	PSP (Passenger's Seat Pneumatic Functions ECU)	●	●	●	●	●
5008	5008	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
5008	5008	RBS (Rain And Brightness Sensor)	●	●	●	●	●
5008	5008	RSS (Rain-sunlight Sensor)	●	●	●	●	●

5008	5008	Radio	●	●	●	●	●
5008	5008	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
5008	5008	SHP/VR (Front Left Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
5008	5008	SHP/VR (Front Right Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
5008	5008	SM (Services Module)	●	●	●	●	●
5008	5008	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
5008	5008	SRS (Airbag)	●	●	●	●	●
5008	5008	SWC (Controls On The Steering Wheel)	●	●	●	●	●
5008	5008	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
5008	5008	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
5008	5008	Siren	●	●	●	●	●
5008	5008	TCM (Automatic Gearbox)	●	●	●	●	●
5008	5008	TCM (Sequential Gear Lever)	●	●	●	●	●
5008	5008	TEU (Telematics Unit)	●	●	●	●	●
5008	5008	TRU (Trailer Relay Unit)	●	●	●	●	●
5008	5008	TS (Touch Screen)	●	●	●	●	●
5008	5008	UID (Under Inflation Detection)	●	●	●	●	●
5008	5008	VDA (Vehicle Distance Assistance)	●	●	●	●	●
5008	5008	VRD (Voltage Retaining Device)	●	●	●	●	●
5008	5008	Wiper (Windscreen Wiper)	●	●	●	●	●
5008	5008 (P84)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
5008	5008 (P84)	AC (Air Conditioning)	●	●	●	●	●
5008	5008 (P84)	AC (Rear Air Conditioning)	●	●	●	●	●
5008	5008 (P84)	ALM (Anti-theft Alarm)	●	●	●	●	●
5008	5008 (P84)	AMP (Audio Amplifier)	●	●	●	●	●
5008	5008 (P84)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
5008	5008 (P84)	BATT (Battery Charge Status Unit)	●	●	●	●	●
5008	5008 (P84)	BCM (Body Control Module)	●	●	●	●	●
5008	5008 (P84)	BSI (Built-in Systems Interface)	●	●	●	●	●
5008	5008 (P84)	CD (External CD Player)	●	●	●	●	●
5008	5008 (P84)	DAF (Diesel Additive Pump)	●	●	●	●	●
5008	5008 (P84)	DDC (Driver's Door Control Panel)	●	●	●	●	●
5008	5008 (P84)	DHL (Headlamp Height Adjuster/Directional Headlamp)	●	●	●	●	●
5008	5008 (P84)	DSC (Driver's Seat Comfort ECU)	●	●	●	●	●
5008	5008 (P84)	DSP (Driver's Seat Pneumatic Functions ECU)	●	●	●	●	●
5008	5008 (P84)	Display	●	●	●	●	●
5008	5008 (P84)	ECM (Engine Control Module)	●	●	●	●	●
5008	5008 (P84)	EPS (Electric Power Steering)	●	●	●	●	●
5008	5008 (P84)	ERU (Engine Relay Unit)	●	●	●	●	●
5008	5008 (P84)	ESL (Electric Steering Lock)	●	●	●	●	●
5008	5008 (P84)	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
5008	5008 (P84)	IP (Instrument Cluster Panel)	●	●	●	●	●
5008	5008 (P84)	MCP (Multiplexed Control Panel)	●	●	●	●	●
5008	5008 (P84)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
5008	5008 (P84)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
5008	5008 (P84)	PAM (Parking Assistance)	●	●	●	●	●
5008	5008 (P84)	PSP (Passenger's Seat Pneumatic Functions ECU)	●	●	●	●	●
5008	5008 (P84)	PVA (Panoramic Visual Assistance ECU)	●	●	●	●	●
5008	5008 (P84)	RSS (Rain-sunlight Sensor)	●	●	●	●	●
5008	5008 (P84)	Radio	●	●	●	●	●
5008	5008 (P84)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
5008	5008 (P84)	SHP/VR (Front Left Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
5008	5008 (P84)	SHP/VR (Front Right Seat Heated Pads And Ventilation Regulation ECU)	●	●	●	●	●
5008	5008 (P84)	SM (Services Module)	●	●	●	●	●
5008	5008 (P84)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
5008	5008 (P84)	SRS (Airbag)	●	●	●	●	●
5008	5008 (P84)	SWC (Controls On The Steering Wheel)	●	●	●	●	●
5008	5008 (P84)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
5008	5008 (P84)	Siren	●	●	●	●	●
5008	5008 (P84)	TCM (Automatic Gearbox)	●	●	●	●	●

5008	5008 (P84)	TCM (Sequential Gear Lever)	●	●	●	●	●
5008	5008 (P84)	TRU (Trailer Relay Unit)	●	●	●	●	●
5008	5008 (P84)	TS (Touch Screen)	●	●	●	●	●
5008	5008 (P84)	VDA (Vehicle Distance Assistance)	●	●	●	●	●
5008	5008 (P84)	VRD (Voltage Retaining Device)	●	●	●	●	●
5008	5008 (P84)	Wiper (Windscreen Wiper)	●	●	●	●	●
508	508	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
508	508	AC (Air Conditioning)	●	●	●	●	●
508	508	AC (Rear Air Conditioning)	●	●	●	●	●
508	508	AH (Additional Heating)	●	●	●	●	●
508	508	AMP (Radio Amplifier)	●	●	●	●	●
508	508	Alarm	●	●	●	●	●
508	508	BATT (Battery Charge Status Unit)	●	●	●	●	●
508	508	BATT (Traction Battery ECU)	●	●	●	●	●
508	508	BSI (Built-in Systems Interface)	●	●	●	●	●
508	508	DBVHA (Discharge Bulbs Vertical And Horizontal Adjustment)	●	●	●	●	●
508	508	DDC (Driver's Door Control Panel)	●	●	●	●	●
508	508	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
508	508	ECM (Engine Control Module)	●	●	●	●	●
508	508	EPB (Electric Secondary Brake)	●	●	●	●	●
508	508	EPS (Electric Power Steering GEP)	●	●	●	●	●
508	508	ERU (Engine Relay Unit)	●	●	●	●	●
508	508	ESL (Electric Steering Lock)	●	●	●	●	●
508	508	HFC (Hands Free Control Kit)	●	●	●	●	●
508	508	HHV (High Head Vision)	●	●	●	●	●
508	508	HMS (Hybrid Mode Selector)	●	●	●	●	●
508	508	HYC-1 (Hybrid Control ECU 1)	●	●	●	●	●
508	508	HYC-2 (Hybrid Control ECU 2)	●	●	●	●	●
508	508	IP (Instrument Cluster Panel)	●	●	●	●	●
508	508	KEY (Electronic Key Reader)	●	●	●	●	●
508	508	MBA (Main Beams Assistant)	●	●	●	●	●
508	508	MCP (Multiplexed Control Panel)	●	●	●	●	●
508	508	MOTO (Motorised Boot ECU)	●	●	●	●	●
508	508	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
508	508	MULS (Multifunction Screen)	●	●	●	●	●
508	508	NAVI (Telematic Navigator)	●	●	●	●	●
508	508	PAM (Parking Assistance)	●	●	●	●	●
508	508	RBS (Rain And Brightness Sensor)	●	●	●	●	●
508	508	Radio	●	●	●	●	●
508	508	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
508	508	SM (Services Module)	●	●	●	●	●
508	508	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
508	508	SRS (Airbag)	●	●	●	●	●
508	508	SSP (Active Damper Electronic Unit)	●	●	●	●	●
508	508	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
508	508	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
508	508	TCM (Automatic Gearbox)	●	●	●	●	●
508	508	TEU/NAVI (Telematics Unit(Rtx) Or Radio-navigation)	●	●	●	●	●
508	508	TRU (Trailer Relay Unit)	●	●	●	●	●
508	508	UID (Under Inflation Detection)	●	●	●	●	●
508	508	VRD (Voltage Retaining Device)	●	●	●	●	●
508	508	Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
508	508	Wiper-R (Windscreen Wiper (Right-hand Side))	●	●	●	●	●
508	508 (Hybrid4)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
508	508 (Hybrid4)	AC (Air Conditioning)	●	●	●	●	●
508	508 (Hybrid4)	AC (Rear Air Conditioning)	●	●	●	●	●
508	508 (Hybrid4)	AH (Additional Heating)	●	●	●	●	●
508	508 (Hybrid4)	ALM (Anti-theft Alarm)	●	●	●	●	●
508	508 (Hybrid4)	AMP (Audio Amplifier)	●	●	●	●	●
508	508 (Hybrid4)	BATT (Battery Charge Status Unit)	●	●	●	●	●
508	508 (Hybrid4)	BATT (Traction Battery ECU)	●	●	●	●	●

508	508 (Hybrid4)	BSI (Built-in Systems Interface)	●	●	●	●	●
508	508 (Hybrid4)	DBVHA (Discharge Bulbs Vertical And Horizontal Adjustment)	●	●	●	●	●
508	508 (Hybrid4)	DCP (Door Control Pad)	●	●	●	●	●
508	508 (Hybrid4)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
508	508 (Hybrid4)	ECM (Engine Control Module)	●	●	●	●	●
508	508 (Hybrid4)	EPB (Electric Secondary Brake)	●	●	●	●	●
508	508 (Hybrid4)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
508	508 (Hybrid4)	ERU (Engine Relay Unit)	●	●	●	●	●
508	508 (Hybrid4)	ESL (Electric Steering Lock)	●	●	●	●	●
508	508 (Hybrid4)	HFC (Hands Free Control Kit)	●	●	●	●	●
508	508 (Hybrid4)	HHV (High Head Vision)	●	●	●	●	●
508	508 (Hybrid4)	HMS (Hybrid Mode Selector)	●	●	●	●	●
508	508 (Hybrid4)	HYC-1 (Hybrid Control ECU 1)	●	●	●	●	●
508	508 (Hybrid4)	HYC-2 (Hybrid Control ECU 2)	●	●	●	●	●
508	508 (Hybrid4)	IP (Instrument Cluster Panel)	●	●	●	●	●
508	508 (Hybrid4)	KEY (Electronic Key Reader)	●	●	●	●	●
508	508 (Hybrid4)	MBA (Main Beams Assistant)	●	●	●	●	●
508	508 (Hybrid4)	MCP (Multiplexed Control Panel)	●	●	●	●	●
508	508 (Hybrid4)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
508	508 (Hybrid4)	MULD (Multifunction Display)	●	●	●	●	●
508	508 (Hybrid4)	NAVI (Telematic Navigator)	●	●	●	●	●
508	508 (Hybrid4)	PAM (Parking Assistance)	●	●	●	●	●
508	508 (Hybrid4)	Radio RD5	●	●	●	●	●
508	508 (Hybrid4)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
508	508 (Hybrid4)	SM (Services Module)	●	●	●	●	●
508	508 (Hybrid4)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
508	508 (Hybrid4)	SRS (Airbag)	●	●	●	●	●
508	508 (Hybrid4)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
508	508 (Hybrid4)	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
508	508 (Hybrid4)	TCM (Automatic Gearbox)	●	●	●	●	●
508	508 (Hybrid4)	TEU (Telematics Unit)	●	●	●	●	●
508	508 (Hybrid4)	TRU (Trailer Relay Unit)	●	●	●	●	●
508	508 (Hybrid4)	UID (Under Inflation Detection)	●	●	●	●	●
508	508 (Hybrid4)	VRD (Voltage Retaining Device)	●	●	●	●	●
508	508 (Hybrid4)	Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
508	508 (Hybrid4)	Wiper-R (Windscreen Wiper (Right-hand Side))	●	●	●	●	●
508	508 (RXH Hybrid4)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
508	508 (RXH Hybrid4)	AC (Air Conditioning)	●	●	●	●	●
508	508 (RXH Hybrid4)	AC (Rear Air Conditioning)	●	●	●	●	●
508	508 (RXH Hybrid4)	AH (Additional Heating)	●	●	●	●	●
508	508 (RXH Hybrid4)	ALM (Anti-theft Alarm)	●	●	●	●	●
508	508 (RXH Hybrid4)	AMP (Audio Amplifier)	●	●	●	●	●
508	508 (RXH Hybrid4)	BATT (Battery Charge Status Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	BATT (Traction Battery ECU)	●	●	●	●	●
508	508 (RXH Hybrid4)	BSI (Built-in Systems Interface)	●	●	●	●	●
508	508 (RXH Hybrid4)	DBVHA (Discharge Bulbs Vertical And Horizontal Adjustment)	●	●	●	●	●
508	508 (RXH Hybrid4)	DCP (Door Control Pad)	●	●	●	●	●
508	508 (RXH Hybrid4)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	ECM (Engine Control Module)	●	●	●	●	●
508	508 (RXH Hybrid4)	EPB (Electric Secondary Brake)	●	●	●	●	●
508	508 (RXH Hybrid4)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	ERU (Engine Relay Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	ESL (Electric Steering Lock)	●	●	●	●	●
508	508 (RXH Hybrid4)	HFC (Hands Free Control Kit)	●	●	●	●	●
508	508 (RXH Hybrid4)	HHV (High Head Vision)	●	●	●	●	●
508	508 (RXH Hybrid4)	HMS (Hybrid Mode Selector)	●	●	●	●	●
508	508 (RXH Hybrid4)	HYC-1 (Hybrid Control ECU 1)	●	●	●	●	●
508	508 (RXH Hybrid4)	HYC-2 (Hybrid Control ECU 2)	●	●	●	●	●
508	508 (RXH Hybrid4)	IP (Instrument Cluster Panel)	●	●	●	●	●
508	508 (RXH Hybrid4)	KEY (Electronic Key Reader)	●	●	●	●	●
508	508 (RXH Hybrid4)	MBA (Main Beams Assistant)	●	●	●	●	●

508	508 (RXH Hybrid4)	MCP (Multiplexed Control Panel)	●	●	●	●	●
508	508 (RXH Hybrid4)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
508	508 (RXH Hybrid4)	MULD (Multifunction Display)	●	●	●	●	●
508	508 (RXH Hybrid4)	NAVI (Telematic Navigator)	●	●	●	●	●
508	508 (RXH Hybrid4)	PAM (Parking Assistance)	●	●	●	●	●
508	508 (RXH Hybrid4)	Radio RD5	●	●	●	●	●
508	508 (RXH Hybrid4)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
508	508 (RXH Hybrid4)	SM (Services Module)	●	●	●	●	●
508	508 (RXH Hybrid4)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	SRS (Airbag)	●	●	●	●	●
508	508 (RXH Hybrid4)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
508	508 (RXH Hybrid4)	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
508	508 (RXH Hybrid4)	TCM (Automatic Gearbox)	●	●	●	●	●
508	508 (RXH Hybrid4)	TEU (Telematics Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	TRU (Trailer Relay Unit)	●	●	●	●	●
508	508 (RXH Hybrid4)	UID (Under Inflation Detection)	●	●	●	●	●
508	508 (RXH Hybrid4)	VRD (Voltage Retaining Device)	●	●	●	●	●
508	508 (RXH Hybrid4)	Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
508	508 (RXH Hybrid4)	Wiper-R (Windscreen Wiper (Right-hand Side))	●	●	●	●	●
508	508 (RXH)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
508	508 (RXH)	AC (Air Conditioning)	●	●	●	●	●
508	508 (RXH)	AC (Rear Air Conditioning)	●	●	●	●	●
508	508 (RXH)	AH (Additional Heating)	●	●	●	●	●
508	508 (RXH)	ALM (Anti-theft Alarm)	●	●	●	●	●
508	508 (RXH)	AMP (Audio Amplifier)	●	●	●	●	●
508	508 (RXH)	BATT (Battery Charge Status Unit)	●	●	●	●	●
508	508 (RXH)	BATT (Traction Battery ECU)	●	●	●	●	●
508	508 (RXH)	BSI (Built-in Systems Interface)	●	●	●	●	●
508	508 (RXH)	DBVHA (Discharge Bulbs Vertical And Horizontal Adjustment)	●	●	●	●	●
508	508 (RXH)	DCP (Door Control Pad)	●	●	●	●	●
508	508 (RXH)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
508	508 (RXH)	ECM (Engine Control Module)	●	●	●	●	●
508	508 (RXH)	EPB (Electric Secondary Brake)	●	●	●	●	●
508	508 (RXH)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
508	508 (RXH)	ERU (Engine Relay Unit)	●	●	●	●	●
508	508 (RXH)	ESL (Electric Steering Lock)	●	●	●	●	●
508	508 (RXH)	HFC (Hands Free Control Kit)	●	●	●	●	●
508	508 (RXH)	HHV (High Head Vision)	●	●	●	●	●
508	508 (RXH)	HMS (Hybrid Mode Selector)	●	●	●	●	●
508	508 (RXH)	HYC-1 (Hybrid Control ECU 1)	●	●	●	●	●
508	508 (RXH)	HYC-2 (Hybrid Control ECU 2)	●	●	●	●	●
508	508 (RXH)	IP (Instrument Cluster Panel)	●	●	●	●	●
508	508 (RXH)	KEY (Electronic Key Reader)	●	●	●	●	●
508	508 (RXH)	MBA (Main Beams Assistant)	●	●	●	●	●
508	508 (RXH)	MCP (Multiplexed Control Panel)	●	●	●	●	●
508	508 (RXH)	MSI (Matrix Screen Integral To The Instrument Panel)	●	●	●	●	●
508	508 (RXH)	MULD (Multifunction Display)	●	●	●	●	●
508	508 (RXH)	NAVI (Telematic Navigator)	●	●	●	●	●
508	508 (RXH)	PAM (Parking Assistance)	●	●	●	●	●
508	508 (RXH)	Radio RD5	●	●	●	●	●
508	508 (RXH)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
508	508 (RXH)	SM (Services Module)	●	●	●	●	●
508	508 (RXH)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
508	508 (RXH)	SRS (Airbag)	●	●	●	●	●
508	508 (RXH)	SWIC (Steering Wheel With Integral Controls (VCI))	●	●	●	●	●
508	508 (RXH)	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
508	508 (RXH)	TCM (Automatic Gearbox)	●	●	●	●	●
508	508 (RXH)	TEU (Telematics Unit)	●	●	●	●	●
508	508 (RXH)	TRU (Trailer Relay Unit)	●	●	●	●	●
508	508 (RXH)	UID (Under Inflation Detection)	●	●	●	●	●
508	508 (RXH)	VRD (Voltage Retaining Device)	●	●	●	●	●

508	508 (RXH)	Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
508	508 (RXH)	Wiper-R (Windscreen Wiper (Right-hand Side))	●	●	●	●	●
607	607 (CAN)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
607	607 (CAN)	AC (Air Conditioning)	●	●	●	●	●
607	607 (CAN)	Alarm	●	●	●	●	●
607	607 (CAN)	BSI (Built-in Systems Interface)	●	●	●	●	●
607	607 (CAN)	CD (CD Player)	●	●	●	●	●
607	607 (CAN)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
607	607 (CAN)	DDM (Driver's Door Module)	●	●	●	●	●
607	607 (CAN)	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
607	607 (CAN)	ECM (Engine Control Module)	●	●	●	●	●
607	607 (CAN)	EPS (Electric Power Steering GEP)	●	●	●	●	●
607	607 (CAN)	HFC (Hands Free Control Kit)	●	●	●	●	●
607	607 (CAN)	IP (Instrument Cluster Panel)	●	●	●	●	●
607	607 (CAN)	MULS (Multifunction Screen)	●	●	●	●	●
607	607 (CAN)	PAM (Parking Assistance)	●	●	●	●	●
607	607 (CAN)	PDM (Passenger's Door Module)	●	●	●	●	●
607	607 (CAN)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
607	607 (CAN)	Radio	●	●	●	●	●
607	607 (CAN)	SRS (Airbag)	●	●	●	●	●
607	607 (CAN)	SSP (Electronically Managed Suspension)	●	●	●	●	●
607	607 (CAN)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
607	607 (CAN)	TCM (AM6 Automatic Gearbox)	●	●	●	●	●
607	607 (CAN)	TCM (BVA ZF)	●	●	●	●	●
607	607 (CAN)	TEU (Telematics Unit)	●	●	●	●	●
607	607 (CAN)	UID (Under Inflation Detection)	●	●	●	●	●
607	607 (VAN)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
607	607 (VAN)	AC (Air Conditioning)	●	●	●	●	●
607	607 (VAN)	BSI (Built-in Systems Interface)	●	●	●	●	●
607	607 (VAN)	CD (CD Player)	●	●	●	●	●
607	607 (VAN)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
607	607 (VAN)	DDC (Driver's Door Control Panel)	●	●	●	●	●
607	607 (VAN)	DPOS (Storing Of The Driving Position)	●	●	●	●	●
607	607 (VAN)	ECM (Engine Control Module)	●	●	●	●	●
607	607 (VAN)	HLH (Headlamp Height Corrector)	●	●	●	●	●
607	607 (VAN)	IP (Instrument Cluster Panel)	●	●	●	●	●
607	607 (VAN)	MULS (Multifunction Screen)	●	●	●	●	●
607	607 (VAN)	PAM (Parking Assistance)	●	●	●	●	●
607	607 (VAN)	PDC (Passenger's Door Control Panel)	●	●	●	●	●
607	607 (VAN)	Radio	●	●	●	●	●
607	607 (VAN)	SRS (Airbag)	●	●	●	●	●
607	607 (VAN)	SSP (Electronically Managed Suspension)	●	●	●	●	●
607	607 (VAN)	TCM (Automatic Gearbox)	●	●	●	●	●
806		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
806		AH (Additional Heating)	●	●	●	●	●
806		ECM (Engine Control Module)	●	●	●	●	●
806		SRS (Airbag)	●	●	●	●	●
806		TCM (Automatic Gearbox)	●	●	●	●	●
807	807 (CAN) (2005 - )	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
807	807 (CAN) (2005 - )	AC (Air Conditioning)	●	●	●	●	●
807	807 (CAN) (2005 - )	AH (Additional Heating)	●	●	●	●	●
807	807 (CAN) (2005 - )	Alarm	●	●	●	●	●
807	807 (CAN) (2005 - )	BSI (Built-in Systems Interface)	●	●	●	●	●
807	807 (CAN) (2005 - )	CD (CD Player)	●	●	●	●	●
807	807 (CAN) (2005 - )	DAF (Diesel Additive Control Unit)	●	●	●	●	●
807	807 (CAN) (2005 - )	DDM (Driver's Door Module)	●	●	●	●	●
807	807 (CAN) (2005 - )	DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
807	807 (CAN) (2005 - )	ECM (Engine Control Module)	●	●	●	●	●
807	807 (CAN) (2005 - )	EPS (Electric Power Steering GEP)	●	●	●	●	●
807	807 (CAN) (2005 - )	HFC (Hands Free Control Kit)	●	●	●	●	●
807	807 (CAN) (2005 - )	HLLC (Left Headlamp Beam Level Corrector)	●	●	●	●	●

807	807 (CAN) (2005 - )	HLRC (Right Headlamp Beam Corrector)	●	●	●	●	●
807	807 (CAN) (2005 - )	IP (Instrument Cluster Panel)	●	●	●	●	●
807	807 (CAN) (2005 - )	IP (Warning Lights/Odometer Unit)	●	●	●	●	●
807	807 (CAN) (2005 - )	MULS (Multifunction Screen)	●	●	●	●	●
807	807 (CAN) (2005 - )	PAM (Parking Assistance)	●	●	●	●	●
807	807 (CAN) (2005 - )	PDM (Passenger's Door Module)	●	●	●	●	●
807	807 (CAN) (2005 - )	RBS (Rain And Brightness Sensor)	●	●	●	●	●
807	807 (CAN) (2005 - )	Radio	●	●	●	●	●
807	807 (CAN) (2005 - )	SR-F (Front Sunroof)	●	●	●	●	●
807	807 (CAN) (2005 - )	SR-M (Middle Sunroof)	●	●	●	●	●
807	807 (CAN) (2005 - )	SR-R (Rear Sunroof)	●	●	●	●	●
807	807 (CAN) (2005 - )	SRS (Airbag)	●	●	●	●	●
807	807 (CAN) (2005 - )	SSDM (Sliding Side Doors Module)	●	●	●	●	●
807	807 (CAN) (2005 - )	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
807	807 (CAN) (2005 - )	TCM (Automatic Gearbox)	●	●	●	●	●
807	807 (CAN) (2005 - )	TEU (Telematics Unit)	●	●	●	●	●
807	807 (CAN) (2005 - )	TRC (Telematic Receiver Control)	●	●	●	●	●
807	807 (CAN) (2005 - )	UID (Under Inflation Detection)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	AC (Air Conditioning)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	AH (Additional Heating)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	Alarm	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	BSI (Built-in Systems Interface)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	CD (CD Player)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	DAF (Diesel Additive Control Unit)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	DDM (Driver's Door Module)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	DPOS (Storing Of The Driving Position)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	Display/Telematics	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	ECM (Engine Control Module)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	HLLC (Left Headlamp Beam Level Corrector)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	HLRC (Right Headlamp Beam Corrector)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	IP (Instrument Cluster Panel)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	IP (Warning Lights/Odometer Unit)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	PAM (Parking Assistance)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	PDM (Passenger's Door Module)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	Radio	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	SRS (Airbag)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	SSDM (Sliding Side Doors Module)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
807	807 (VAN) (2002 - 2005)	TCM (Automatic Gearbox)	●	●	●	●	●
BIPPER		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
BIPPER		BSI (Built-in Systems Interface)	●	●	●	●	●
BIPPER		ECM (Engine Control Module)	●	●	●	●	●
BIPPER		IP (Instrument Cluster Panel)	●	●	●	●	●
BIPPER		PAM (Parking Assistance)	●	●	●	●	●
BIPPER		SRS (Airbag)	●	●	●	●	●
BIPPER		TCM (Automatic Gearbox)	●	●	●	●	●
BOXER	BOXER (1)	ECM (Engine Control Module)	●	●	●	●	●
BOXER	BOXER (1)	TCM (Automatic Gearbox)	●	●	●	●	●
BOXER	BOXER (3)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
BOXER	BOXER (3)	AC (Air Conditioning)	●	●	●	●	●
BOXER	BOXER (3)	AH (Additional Heating)	●	●	●	●	●
BOXER	BOXER (3)	BSI (Built-in Systems Interface)	●	●	●	●	●
BOXER	BOXER (3)	ECM (Engine Control Module)	●	●	●	●	●
BOXER	BOXER (3)	EPS (Electric Power Steering GEP)	●	●	●	●	●
BOXER	BOXER (3)	IP (Instrument Cluster Panel)	●	●	●	●	●
BOXER	BOXER (3)	LDWS (Lane Departure Warning System)	●	●	●	●	●
BOXER	BOXER (3)	PAM (Parking Assistance)	●	●	●	●	●
BOXER	BOXER (3)	SRS (Airbag)	●	●	●	●	●
BOXER	BOXER (3)	SSP (Electronically Managed Suspension)	●	●	●	●	●
BOXER	BOXER (3)	TEU/NAVI (Telematics Unit(Rtx) Or Radio-navigation)	●	●	●	●	●

BOXER	BOXER (3)	TG (Tachograph)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	AC (Air Conditioning)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	AH (Additional Heating)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	BSI (Built-in Systems Interface)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	ECM (Engine Control Module)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	EPS (Electric Power Steering)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	IP (Instrument Cluster Panel)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	LDWS (Lane Departure Warning System)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	PAM (Parking Assistance)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	SRS (Airbag)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	SSP (Electronically Managed Suspension)	●	●	●	●	●
BOXER	BOXER (3) (Euro 5 / 6)	TG (Tachograph)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	AC (Air Conditioning)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	AH (Additional Heating)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	BSI (Built-in Systems Interface)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	ECM (Engine Control Module)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	EPS (Electric Power Steering GEP)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	IP (Instrument Cluster Panel)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	PAM (Parking Assistance)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	SRS (Airbag)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	SSP (Electronically Managed Suspension)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	TEU/NAVI (Telematics Unit(Rtx) Or Radio-navigation)	●	●	●	●	●
BOXER	BOXER (3) (MiniBus)	TG (Tachograph)	●	●	●	●	●
EXPERT	EXPERT (1)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
EXPERT	EXPERT (1)	AH (Additional Heating)	●	●	●	●	●
EXPERT	EXPERT (1)	ECM (Engine Control Module)	●	●	●	●	●
EXPERT	EXPERT (1)	SRS (Airbag)	●	●	●	●	●
EXPERT	EXPERT (1)	TCM (Automatic Gearbox)	●	●	●	●	●
EXPERT	EXPERT (2)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
EXPERT	EXPERT (2)	AC (Air Conditioning)	●	●	●	●	●
EXPERT	EXPERT (2)	AH (Additional Heating)	●	●	●	●	●
EXPERT	EXPERT (2)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
EXPERT	EXPERT (2)	Alarm	●	●	●	●	●
EXPERT	EXPERT (2)	BSI (Built-in Systems Interface)	●	●	●	●	●
EXPERT	EXPERT (2)	CD (CD Player)	●	●	●	●	●
EXPERT	EXPERT (2)	ECM (Engine Control Module)	●	●	●	●	●
EXPERT	EXPERT (2)	EPS (Electric Power Steering GEP)	●	●	●	●	●
EXPERT	EXPERT (2)	HFC (Hands Free Control Kit)	●	●	●	●	●
EXPERT	EXPERT (2)	IP (Instrument Cluster Panel)	●	●	●	●	●
EXPERT	EXPERT (2)	MULS (Multifunction Screen)	●	●	●	●	●
EXPERT	EXPERT (2)	PAM (Parking Assistance)	●	●	●	●	●
EXPERT	EXPERT (2)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
EXPERT	EXPERT (2)	Radio	●	●	●	●	●
EXPERT	EXPERT (2)	SRS (Airbag)	●	●	●	●	●
EXPERT	EXPERT (2)	SSP (Pneumatic Suspension)	●	●	●	●	●
EXPERT	EXPERT (2)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
EXPERT	EXPERT (2)	TCM (Automatic Gearbox)	●	●	●	●	●
EXPERT	EXPERT (2)	TEU (Telematics Unit)	●	●	●	●	●
EXPERT	EXPERT (2)	UID (Under Inflation Detection)	●	●	●	●	●
EXPERT	EXPERT (3)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
EXPERT	EXPERT (3)	AC (Rear Air Conditioning Table)	●	●	●	●	●
EXPERT	EXPERT (3)	AH (Additional Heating)	●	●	●	●	●
EXPERT	EXPERT (3)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
EXPERT	EXPERT (3)	BATT (Battery Charge Status Unit)	●	●	●	●	●
EXPERT	EXPERT (3)	BSI (Built-in Systems Interface)	●	●	●	●	●
EXPERT	EXPERT (3)	BWCU (Bodywork Conversion Unit)	●	●	●	●	●
EXPERT	EXPERT (3)	CD (CD Player)	●	●	●	●	●
EXPERT	EXPERT (3)	DD (Deflation Detection (Dsg))	●	●	●	●	●
EXPERT	EXPERT (3)	ECM (Engine Control Module)	●	●	●	●	●



EXPERT	EXPERT (3)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
EXPERT	EXPERT (3)	HFC (Hands Free Control Kit)	●	●	●	●	●
EXPERT	EXPERT (3)	HFR (High Frequency Receiver)	●	●	●	●	●
EXPERT	EXPERT (3)	Heating/Ventilation	●	●	●	●	●
EXPERT	EXPERT (3)	IP (Instrument Cluster Panel)	●	●	●	●	●
EXPERT	EXPERT (3)	MULD (Multifunction Display)	●	●	●	●	●
EXPERT	EXPERT (3)	PAM (Parking Assistance)	●	●	●	●	●
EXPERT	EXPERT (3)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
EXPERT	EXPERT (3)	SRS (Airbag)	●	●	●	●	●
EXPERT	EXPERT (3)	SSP (Pneumatic Suspension)	●	●	●	●	●
EXPERT	EXPERT (3)	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
EXPERT	EXPERT (3)	TCM (Automatic Gearbox)	●	●	●	●	●
EXPERT	EXPERT (3)	TEU (Telematics Unit)	●	●	●	●	●
EXPERT	EXPERT (KO)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
EXPERT	EXPERT (KO)	AC (Air Conditioning)	●	●	●	●	●
EXPERT	EXPERT (KO)	AC (Rear Air Conditioning Control Panel)	●	●	●	●	●
EXPERT	EXPERT (KO)	AC (Rear Air Conditioning)	●	●	●	●	●
EXPERT	EXPERT (KO)	AH (Additional Heating)	●	●	●	●	●
EXPERT	EXPERT (KO)	ALM (Anti-theft Alarm)	●	●	●	●	●
EXPERT	EXPERT (KO)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
EXPERT	EXPERT (KO)	BATT (Battery Charge Status Unit)	●	●	●	●	●
EXPERT	EXPERT (KO)	BSI (Built-in Systems Interface)	●	●	●	●	●
EXPERT	EXPERT (KO)	DAF (Diesel Additive Pump)	●	●	●	●	●
EXPERT	EXPERT (KO)	Display	●	●	●	●	●
EXPERT	EXPERT (KO)	ECM (Engine Control Module)	●	●	●	●	●
EXPERT	EXPERT (KO)	ERU (Engine Relay Unit)	●	●	●	●	●
EXPERT	EXPERT (KO)	ESL (Electric Steering Lock)	●	●	●	●	●
EXPERT	EXPERT (KO)	HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
EXPERT	EXPERT (KO)	HHV (High Head Vision)	●	●	●	●	●
EXPERT	EXPERT (KO)	IP (Instrument Cluster Panel)	●	●	●	●	●
EXPERT	EXPERT (KO)	MCP (Multiplexed Control Panel)	●	●	●	●	●
EXPERT	EXPERT (KO)	MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
EXPERT	EXPERT (KO)	NAVI (Telematic Navigator)	●	●	●	●	●
EXPERT	EXPERT (KO)	NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
EXPERT	EXPERT (KO)	PAM (Parking Assistance)	●	●	●	●	●
EXPERT	EXPERT (KO)	RSS (Rain-sunlight Sensor)	●	●	●	●	●
EXPERT	EXPERT (KO)	Radio	●	●	●	●	●
EXPERT	EXPERT (KO)	SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
EXPERT	EXPERT (KO)	SM (Services Module)	●	●	●	●	●
EXPERT	EXPERT (KO)	SPMU (Supply Protection And Management Unit)	●	●	●	●	●
EXPERT	EXPERT (KO)	SRS (Airbag)	●	●	●	●	●
EXPERT	EXPERT (KO)	SSDM (Left-hand Sliding Side Door)	●	●	●	●	●
EXPERT	EXPERT (KO)	SWC (Controls On The Steering Wheel)	●	●	●	●	●
EXPERT	EXPERT (KO)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
EXPERT	EXPERT (KO)	Siren	●	●	●	●	●
EXPERT	EXPERT (KO)	TCM (Automatic Gearbox)	●	●	●	●	●
EXPERT	EXPERT (KO)	TRU (Trailer Relay Unit)	●	●	●	●	●
EXPERT	EXPERT (KO)	TS (Touch Screen)	●	●	●	●	●
EXPERT	EXPERT (KO)	VDA (Vehicle Distance Assistance)	●	●	●	●	●
EXPERT	EXPERT (KO)	VRD (Voltage Retaining Device)	●	●	●	●	●
HOGGAR		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
HOGGAR		AC (Air Conditioning)	●	●	●	●	●
HOGGAR		Alarm	●	●	●	●	●
HOGGAR		BSI (Built-in Systems Interface)	●	●	●	●	●
HOGGAR		CD (CD Player)	●	●	●	●	●
HOGGAR		Display/Telematics	●	●	●	●	●
HOGGAR		ECM (Engine Control Module)	●	●	●	●	●
HOGGAR		IP (Instrument Cluster Panel)	●	●	●	●	●
HOGGAR		RBS (Rain And Brightness Sensor)	●	●	●	●	●
HOGGAR		Radio	●	●	●	●	●
HOGGAR		SM (Services Module)	●	●	●	●	●

HOGGAR		SRS (Airbag)	●	●	●	●	●
HOGGAR		SVLCU (Stolen Vehicle Location Control)	●	●	●	●	●
HOGGAR		SWSM (Steering Wheel Switching Module)	●	●	●	●	●
HOGGAR		TCM (Automatic Gearbox)	●	●	●	●	●
HOGGAR		Wiper-L (Windscreen Wiper (Left-hand Side))	●	●	●	●	●
ION		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
ION		AC (Air Conditioning)	●	●	●	●	●
ION		BATT (Onboard Charger Of The Traction Battery)	●	●	●	●	●
ION		BATT (Traction Battery ECU)	●	●	●	●	●
ION		BATT-01 (Traction Battery Cells Management (Module 01))	●	●	●	●	●
ION		BATT-02 (Traction Battery Cells Management (Module 02))	●	●	●	●	●
ION		BATT-03 (Traction Battery Cells Management (Module 03))	●	●	●	●	●
ION		BATT-04 (Traction Battery Cells Management (Module 04))	●	●	●	●	●
ION		BATT-05 (Traction Battery Cells Management (Module 05))	●	●	●	●	●
ION		BATT-07 (Traction Battery Cells Management (Module 07))	●	●	●	●	●
ION		BATT-08 (Traction Battery Cells Management (Module 08))	●	●	●	●	●
ION		BATT-09 (Traction Battery Cells Management (Module 09))	●	●	●	●	●
ION		BATT-10 (Traction Battery Cells Management (Module 10))	●	●	●	●	●
ION		BATT-11 (Traction Battery Cells Management (Module 11))	●	●	●	●	●
ION		DVT (Direct Voltage (DC/DC) Transformer)	●	●	●	●	●
ION		EMM (Electric Machine Management ECU)	●	●	●	●	●
ION		EPS (Electric Power Steering)	●	●	●	●	●
ION		EVM (Electric Vehicle Management ECU)	●	●	●	●	●
ION		GWH (Gateway Wiring Housing)	●	●	●	●	●
ION		IP (Instrument Cluster Panel)	●	●	●	●	●
ION		RPE (Radio Post-equipment)	●	●	●	●	●
ION		SAS (Steering Wheel Angle Sensor)	●	●	●	●	●
ION		SM (Services Module)	●	●	●	●	●
ION		SRS (Airbag)	●	●	●	●	●
PARTNER	PARTNER (2)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
PARTNER	PARTNER (2)	AC (Air Conditioning)	●	●	●	●	●
PARTNER	PARTNER (2)	AH (Additional Heating)	●	●	●	●	●
PARTNER	PARTNER (2)	Alarm	●	●	●	●	●
PARTNER	PARTNER (2)	BSI (Built-in Systems Interface)	●	●	●	●	●
PARTNER	PARTNER (2)	CD (CD Player)	●	●	●	●	●
PARTNER	PARTNER (2)	ECM (Engine Control Module)	●	●	●	●	●
PARTNER	PARTNER (2)	IP (Instrument Cluster Panel)	●	●	●	●	●
PARTNER	PARTNER (2)	MULD (Multifunction Display)	●	●	●	●	●
PARTNER	PARTNER (2)	RBS (Rain And Brightness Sensor)	●	●	●	●	●
PARTNER	PARTNER (2)	Radio	●	●	●	●	●
PARTNER	PARTNER (2)	SM (Services Module)	●	●	●	●	●
PARTNER	PARTNER (2)	SRS (Airbag)	●	●	●	●	●
PARTNER	PARTNER (2)	SWSM (Steering Wheel Switching Module)	●	●	●	●	●
PARTNER	PARTNER (2)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	BSI (Built-in Systems Interface)	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	ECM (Engine Control Module)	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	IP (Instrument Cluster Panel)	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	Radio	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	SRS (Airbag)	●	●	●	●	●
PARTNER	PARTNER (2) (M69)	SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
PARTNER	PARTNER (B9)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
PARTNER	PARTNER (B9)	AC (Air Conditioning Compressor)	●	●	●	●	●
PARTNER	PARTNER (B9)	AC (Air Conditioning)	●	●	●	●	●
PARTNER	PARTNER (B9)	ASM (Anti-slip Mode Selector)	●	●	●	●	●
PARTNER	PARTNER (B9)	Alarm	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT (Battery Charge Status Unit)	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT (Onboard Charger Of The Traction Battery)	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-01 (Traction Battery Cells Management (Module 01))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-02 (Traction Battery Cells Management (Module 02))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-03 (Traction Battery Cells Management (Module 03))	●	●	●	●	●

PARTNER	PARTNER (B9)	BATT-04 (Traction Battery Cells Management (Module 04))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-05 (Traction Battery Cells Management (Module 05))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-06 (Traction Battery Cells Management (Module 06))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-07 (Traction Battery Cells Management (Module 07))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-08 (Traction Battery Cells Management (Module 08))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-09 (Traction Battery Cells Management (Module 09))	●	●	●	●	●
PARTNER	PARTNER (B9)	BATT-10 (Traction Battery Cells Management (Module 10))	●	●	●	●	●
PARTNER	PARTNER (B9)	BSI (Built-in Systems Interface)	●	●	●	●	●
PARTNER	PARTNER (B9)	BWCU (Bodywork Conversion Unit)	●	●	●	●	●
PARTNER	PARTNER (B9)	CD (CD Player)	●	●	●	●	●
PARTNER	PARTNER (B9)	ECM (Engine Control Module)	●	●	●	●	●
PARTNER	PARTNER (B9)	EMM (Electric Machine Management ECU)	●	●	●	●	●
PARTNER	PARTNER (B9)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
PARTNER	PARTNER (B9)	ERU (Engine Relay Unit)	●	●	●	●	●
PARTNER	PARTNER (B9)	EVM (Electric Vehicle Management ECU)	●	●	●	●	●
PARTNER	PARTNER (B9)	HFC (Hands Free Control Kit)	●	●	●	●	●
PARTNER	PARTNER (B9)	HFR (High Frequency Receiver)	●	●	●	●	●
PARTNER	PARTNER (B9)	IP (Instrument Cluster Panel)	●	●	●	●	●
PARTNER	PARTNER (B9)	MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
PARTNER	PARTNER (B9)	MULD (Multifunction Display)	●	●	●	●	●
PARTNER	PARTNER (B9)	PAM (Parking Assistance)	●	●	●	●	●
PARTNER	PARTNER (B9)	PCAHR (Passenger's Compartment Air Heating Resistor)	●	●	●	●	●
PARTNER	PARTNER (B9)	RS (Rain Sensor)	●	●	●	●	●
PARTNER	PARTNER (B9)	Radio	●	●	●	●	●
PARTNER	PARTNER (B9)	SM (Services Module)	●	●	●	●	●
PARTNER	PARTNER (B9)	SRS (Airbag)	●	●	●	●	●
PARTNER	PARTNER (B9)	SWSM (Switch Module Under The Steering Wheel (Top Of Column))	●	●	●	●	●
PARTNER	PARTNER (B9)	TCM (Automatic Gearbox)	●	●	●	●	●
PARTNER	PARTNER (B9)	TEU/NAVI (Telematics Unit (Rtx) Or Radio-navigation)	●	●	●	●	●
PARTNER	PARTNER (B9)	TRU (Trailer Relay Unit)	●	●	●	●	●
PARTNER	PARTNER (B9)	UID (Under Inflation Detection)	●	●	●	●	●
PARTNER	PARTNER (B9)	VRD (Voltage Retaining Device)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	AC (Air Conditioning Compressor)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	Alarm	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT (Battery Charge Status Unit)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT (Onboard Charger Of The Traction Battery)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-01 (Traction Battery Cells Management (Module 01))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-02 (Traction Battery Cells Management (Module 02))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-03 (Traction Battery Cells Management (Module 03))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-04 (Traction Battery Cells Management (Module 04))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-05 (Traction Battery Cells Management (Module 05))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-06 (Traction Battery Cells Management (Module 06))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-07 (Traction Battery Cells Management (Module 07))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-08 (Traction Battery Cells Management (Module 08))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-09 (Traction Battery Cells Management (Module 09))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BATT-10 (Traction Battery Cells Management (Module 10))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	BSI (Built-in Systems Interface)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	ECM (Engine Control Module)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	EMM (Electric Machine Management ECU)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	EPS (Electric Power Steering Electric Pump Unit)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	ERU (Engine Relay Unit)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	EVM (Electric Vehicle Management ECU)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	IP (Instrument Cluster Panel)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	MULD (Multifunction Display)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	PAM (Parking Assistance)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	PCAHR (Passenger's Compartment Air Heating Resistor)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	RS (Rain Sensor)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	Radio	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	SM (Services Module)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	SRS (Airbag)	●	●	●	●	●

PARTNER	PARTNER Electric (B9E)	SWSM (Switch Module Under The Steering Wheel(Top Of Column))	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	TEU/NAVI (Telematics Unit(Rtx) Or Radio-navigation)	●	●	●	●	●
PARTNER	PARTNER Electric (B9E)	VRD (Voltage Retaining Device)	●	●	●	●	●
RCZ		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
RCZ		AC (Air Conditioning)	●	●	●	●	●
RCZ		AMP (Audio Amplifier)	●	●	●	●	●
RCZ		Alarm	●	●	●	●	●
RCZ		Alarm Lin	●	●	●	●	●
RCZ		BATT (Battery Charge Status Unit)	●	●	●	●	●
RCZ		BSI (Built-in Systems Interface)	●	●	●	●	●
RCZ		CD (CD Player)	●	●	●	●	●
RCZ		CPDMD (Control Panel Dot Matrix Display)	●	●	●	●	●
RCZ		DBVHA (Discharge Bulbs Vertical And Horizontal Adjustment)	●	●	●	●	●
RCZ		DDC (Driver's Door Control Panel)	●	●	●	●	●
RCZ		DSM (Driver's School Module)	●	●	●	●	●
RCZ		DSMU (Driver's Seat Memory Unit)	●	●	●	●	●
RCZ		ECM (Engine Control Module)	●	●	●	●	●
RCZ		EPA (Electropump Assembly)	●	●	●	●	●
RCZ		EPS (Electric Power Steering)	●	●	●	●	●
RCZ		ERU (Engine Relay Unit)	●	●	●	●	●
RCZ		FR (Folding Roof)	●	●	●	●	●
RCZ		HFC (Hands Free Control Kit)	●	●	●	●	●
RCZ		HFR (High Frequency Receiver)	●	●	●	●	●
RCZ		IP (Instrument Cluster Panel)	●	●	●	●	●
RCZ		LDWS (Lane Departure Warning System)	●	●	●	●	●
RCZ		MAAP (Multiplexed Additive Adding Pump)	●	●	●	●	●
RCZ		MPD (Moving Panel Deflector)	●	●	●	●	●
RCZ		MULS (Multifunction Screen)	●	●	●	●	●
RCZ		N-TNB (Not Fastened Warning Light(Tnb))	●	●	●	●	●
RCZ		NAVI (Radio Navigation NG4)	●	●	●	●	●
RCZ		PAM (Parking Assistance)	●	●	●	●	●
RCZ		PID (Pedestrian Impact Detection)	●	●	●	●	●
RCZ		PSM (Passenger's Seat Memorizing Unit)	●	●	●	●	●
RCZ		RBS (Rain And Brightness Sensor)	●	●	●	●	●
RCZ		Radio	●	●	●	●	●
RCZ		SM (Services Module)	●	●	●	●	●
RCZ		SRS (Airbag)	●	●	●	●	●
RCZ		SWSM (Steering Wheel Switching Module)	●	●	●	●	●
RCZ		SunRoof	●	●	●	●	●
RCZ		TCM (Automatic Gearbox)	●	●	●	●	●
RCZ		TEU (Telematics Unit)	●	●	●	●	●
RCZ		TRU (Trailer Relay Unit)	●	●	●	●	●
RCZ		UID (Under Inflation Detection)	●	●	●	●	●
RCZ		VRD (Voltage Retaining Device)	●	●	●	●	●
RCZ		Wiper (Windscreen Wiper)	●	●	●	●	●
TRAVELLER		ABS/ESP (Anti-lock brake System Or Electric Stability Program)	●	●	●	●	●
TRAVELLER		AC (Air Conditioning)	●	●	●	●	●
TRAVELLER		AC (Rear Air Conditioning Control Panel)	●	●	●	●	●
TRAVELLER		AC (Rear Air Conditioning)	●	●	●	●	●
TRAVELLER		AH (Additional Heating)	●	●	●	●	●
TRAVELLER		ALM (Anti-theft Alarm)	●	●	●	●	●
TRAVELLER		ASM (Anti-slip Mode Selector)	●	●	●	●	●
TRAVELLER		BATT (Battery Charge Status Unit)	●	●	●	●	●
TRAVELLER		BSI (Built-in Systems Interface)	●	●	●	●	●
TRAVELLER		DAF (Diesel Additive Pump)	●	●	●	●	●
TRAVELLER		Display	●	●	●	●	●
TRAVELLER		ECM (Engine Control Module)	●	●	●	●	●
TRAVELLER		ERU (Engine Relay Unit)	●	●	●	●	●
TRAVELLER		ESL (Electric Steering Lock)	●	●	●	●	●
TRAVELLER		HFA (Hands Full Access ECU(Right-hand Side Or Rear))	●	●	●	●	●
TRAVELLER		HHV (High Head Vision)	●	●	●	●	●

TRAVELLER		IP (Instrument Cluster Panel)	●	●	●	●	●
TRAVELLER		MCP (Multiplexed Control Panel)	●	●	●	●	●
TRAVELLER		MULC (Multifunction Video Camera (CMF))	●	●	●	●	●
TRAVELLER		NAVI (Telematic Navigator)	●	●	●	●	●
TRAVELLER		NAVI/TEU/CAS (Audio-navigation Or Telematic Unit Or Connected Audio System)	●	●	●	●	●
TRAVELLER		PAM (Parking Assistance)	●	●	●	●	●
TRAVELLER		RSS (Rain-sunlight Sensor)	●	●	●	●	●
TRAVELLER		Radio	●	●	●	●	●
TRAVELLER		SB (Seat Belts Not Fastened LED Unit(TNB))	●	●	●	●	●
TRAVELLER		SM (Services Module)	●	●	●	●	●
TRAVELLER		SPMU (Supply Protection And Management Unit)	●	●	●	●	●
TRAVELLER		SRS (Airbag)	●	●	●	●	●
TRAVELLER		SSDM (Left-hand Sliding Side Door)	●	●	●	●	●
TRAVELLER		SWC (Controls On The Steering Wheel)	●	●	●	●	●
TRAVELLER		SWSM (Switch Module Under The Steering Wheel)	●	●	●	●	●
TRAVELLER		Siren	●	●	●	●	●
TRAVELLER		TCM (Automatic Gearbox)	●	●	●	●	●
TRAVELLER		TRU (Trailer Relay Unit)	●	●	●	●	●
TRAVELLER		TS (Touch Screen)	●	●	●	●	●
TRAVELLER		VDA (Vehicle Distance Assistance)	●	●	●	●	●
TRAVELLER		VRD (Voltage Retaining Device)	●	●	●	●	●