

RollsRoyce EPB Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	EPB
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

EPB Function List

Workshop mode, Automatic Hold brake

Automatic Hold brake: Activate/Deactivate workshop mode

Automatic Hold brake: Start-up

Bedding-in workshop

EMF start-up

EMF: Bedding-in procedure

EMF: Start-up, Automatic Hold brake

EMF: Workshop mode

EMF: Workshop mode, Automatic Hold brake

Parking brake: Bedding-in procedure

Parking brake: EMF start-up

Parking brake: Initial operation

Parking brake: Workshop mode

Start-up, Automatic Hold brake

Workshop mode, Automatic Hold brake